



GE Fanuc Automation

Programmable Control Products

*Series 90™ Micro
Field Processor*

User's Manual

GFK1171

March 1996

Warnings, Cautions, and Notes as Used in this Publication

Warning

Warning notices are used in this publication to emphasize that hazardous voltages, currents, temperatures, or other conditions that could cause personal injury exist in this equipment or may be associated with its use.

In situations where inattention could cause either personal injury or damage to equipment, a Warning notice is used.

Caution

Caution notices are used where equipment might be damaged if care is not taken.

Note

Notes merely call attention to information that is especially significant to understanding and operating the equipment.

This document is based on information available at the time of its publication. While efforts have been made to be accurate, the information contained herein does not purport to cover all details or variations in hardware or software, nor to provide for every possible contingency in connection with installation, operation, or maintenance. Features may be described herein which are not present in all hardware and software systems. GE Fanuc Automation assumes no obligation of notice to holders of this document with respect to changes subsequently made.

GE Fanuc Automation makes no representation or warranty, expressed, implied, or statutory with respect to, and assumes no responsibility for the accuracy, completeness, sufficiency, or usefulness of the information contained herein. No warranties of merchantability or fitness for purpose shall apply.

The following are trademarks of GE Fanuc Automation North America, Inc.

Alarm Master	GEnet	PowerMotion	Series One
CIMPLICITY	Genius	ProLoop	Series Six
CIMPLICITY PowerTRAC	Genius PowerTRAC	PROMACRO	Series Three
CIMPLICITY 90-ADS	Helpmate	Series Five	VuMaster
CIMSTAR	Logicmaster	Series 90	Workmaster
Field Control	Modelmaster		

This manual provides the information necessary to enable you to integrate a Series 90™ Micro Field Processor (IC670MFP100) into a Field Control™ system. The contents of this manual include hardware description, installation procedures, operation information, and diagnostics information for the Series 90 Micro Field Processor.

Content of this Manual

Chapter 1. Introduction. Provides an overview of the Series 90 Micro Field Processor (MFP). Includes physical and functional characteristics and specifications.

Chapter 2. Installation. Describes the procedures for installing the MFP in a Field Control station and connecting a programming device.

Chapter 3. BIU Configuration. Describes how to configure the BIU and the MFP parameters within the BIU to operate within a Field Control station.

Chapter 4. MFP Configuration. Describes how to configure the internal parameters of the MFP.

Chapter 5. Operation. Describes the operation of the MFP. Includes the PLC system sweep sequence, the system power-up and power-down sequences, clocks and timers, system security, and I/O scanning.

Chapter 6. Diagnostics. Provides a guide to troubleshooting the MFP. Describes how to use the LED blink codes that the MFP generates if the unit fails the power-up self-test. Discusses how the MFP handles system faults.

Appendix A. Software Instructions and Reference Types. Lists the LogiMaster 90 instructions supported by the MFP.

Appendix B. Instruction Timing. Contains tables showing the memory size in bytes and the execution time in microseconds for each function.

Appendix C. Configuration File Format. Contains an example format for MFP module configuration within the BIU.

Related Publications

Field Control

Field Control™ Distributed I/O and Control System I/O Modules User's Manual
(GFK-0826)

Field Control™ Distributed I/O and Control System Genius® Bus Interface Unit User's Manual (GFK-0825)

Genius® I/O System User's Manual (GEK-90486-1)

® Genius is a registered trademark of GE Fanuc Automation North America, Inc.

Programming Devices

Logicmaster™ 90-30/20/Micro Programming Software User's Manual (GFK-0466)

Series 90™ -30/20/Micro Programmable Controllers Reference Manual (GFK-0467)

Series 90™ -30/90-20 Programmable Controllers Reference Manual (GFK-0467)

Workmaster® II PLC Programming Unit Guide to Operation Manual (GFK-0401)

Series 90™ -30 and 90-20 PLC Hand-Held Programmer User's Manual (GFK-0402)

Genius® Hand-Held Monitor User's Guide (GFK-0121)

Standards and Specifications

GE Fanuc Product Approvals, Standards, General Specifications (GFK-0867B or later)

We Welcome Your Comments and Suggestions

At GE Fanuc automation, we strive to produce quality technical documentation. After you have used this manual, please take a few moments to complete and return the Reader's Comment Card located on the next page.

Libby Allen
Senior Technical Writer

Chapter 1	Introduction	1-1
	Compatibility	1-3
	Functional Description	1-4
	CPU Board	1-4
	Interface Connectors	1-4
	Status Indicators	1-5
	Configuration and Programming	1-6
	BIU Configuration	1-6
	MFP Configuration	1-6
	Fault Reporting	1-7
	Specifications	1-7
Chapter 2	Installation	2-1
	Minimum Requirements	2-1
	Unpacking	2-1
	Installation	2-2
	Grounding Procedures	2-2
	Mounting the MFP on a Terminal Block	2-3
	Power-up Self-test	2-4
	Connecting a Programming Device	2-5
	Connecting the Hand-Held Programmer	2-5
	Connections for Using Logicmaster 90 Software	2-7
Chapter 3	BIU Configuration	3-1
	MFP Default Configuration	3-1
	I/O Mapping Overview	3-2
	Reference Parameters Overview	3-3
	Reference Parameter Examples	3-4
	Default/Hold Last State Configuration Overview	3-10
	Network Mapping	3-10
	BIU Outputs	3-10
	BIU Inputs	3-12
	How to Configure Reference Parameters	3-13
	HHM Screen Elements	3-13
	Sample Screen Sequence for Reference Parameters	3-14
	Screen Sequence for Default/Hold Last State Configuration	3-16
	Error Messages for Reference Parameters	3-17
	Group Data Moves Overview	3-18
	How to Configure Group Data Moves	3-19
	Screen Sequence for Configuring Groups	3-19
	How to Configure Default/Hold Last State for Group Moves	3-22
	How to Configure Selective Scanning of Group Data Moves	3-24

Contents

Chapter 4	MFP Configuration	4-1
	Using the HHP to Configure and Program the MFP	4-3
	HHP Configuration Screens	4-3
	Storing the User Program Using the HHP	4-4
	Storing Configuration and Register Data Using the HHP	4-5
	Other HHP Functions	4-5
	Using Logicmaster 90 Software to Configure the MFP	4-6
	Using Datagrams	4-7
	Placing the MFP in Stop/No I/O Mode	4-7
	Datagrams Used for MFP/BIU Communication	4-7
Chapter 5	System Operation	5-1
	PLC Sweep Summary	5-1
	MFP and BIU Synchronization	5-2
	Sweep Time Contribution	5-3
	Normal Sweep Processes	5-3
	Deviations from the Standard Program Sweep	5-5
	BIU/MFP Mode Correlation	5-5
	Software Structure	5-6
	Program Structure	5-6
	Data Structure	5-6
	Power-Up and Power-Down Sequences	5-8
	Power-Up Sequence	5-8
	Power-Down Conditions	5-8
	Clocks and Timers	5-10
	System Security	5-11
	Overview	5-11
	Password Protection	5-11
	Diagnostic Data	5-13
	Flash Memory	5-13
Chapter 6	Diagnostics	6-1
	Power-up Diagnostics	6-2
	Faults and Fault Handling	6-3
	Fault Handling	6-3
	Classes of Faults	6-3
	System Response to Faults	6-4
	MFP Fault Conditions	6-7
	Accessing Additional Fault Information	6-9
	Technical Help	6-9

Appendix A Software Instructions and Reference Types	A-1
Instructions and Function Blocks	A-1
Basic Instructions (Relay Ladder Contacts and Coils)	A-1
Timers and Counters	A-2
Math Functions	A-2
Conversion Functions	A-2
Relational Functions	A-3
Bit Operation Functions	A-3
Data Move Functions	A-4
Control Functions	A-4
Table Functions	A-5
User References	A-6
References for Fault Reporting	A-6
Appendix B Instruction Timing	B-1
Appendix C Configuration File Format	C-1

Contents

Figure 1-1. Series 90 Micro Field Processor	1-1
Figure 1-2. Field Control Station Block Diagram	1-2
Figure 1-3. Overview of MFP Interaction with the BIU	1-2
Figure 1-4. Micro Field Processor Functional Block Diagram	1-5
Figure 2-1. Hand-Held Programmer	2-5
Figure 2-2. Hand-Held Programmer Cable Connection to a Micro Field Processor	2-6
Figure 2-3. Logicmaster 90 Programmer to MFP Connection through a WSI	2-7
Figure 2-4. Examples of Serial Connection from Computer to MFP	2-8
Figure 2-5. Series 90 SNP to RS-232 Adapter	2-9
Figure 3-1. BIU Reference Parameters Described as Data Move Function Blocks	3-3
Figure 3-2. Reference Parameter Mapping for Example 1	3-4
Figure 3-3. Move Function Blocks for Example 1	3-5
Figure 3-4. Reference Parameter Mapping for Example 2	3-6
Figure 3-5. Move Function Blocks for Example 2	3-7
Figure 3-6. Reference Parameter Mapping for Example 3	3-8
Figure 3-7. Move Function Blocks for Example 3	3-9
Figure 3-8. Default/Hold Last State Configuration Parameters for BIU Outputs	3-11
Figure 3-9. Case Where Default/Hold Last State Parameter Does Not Apply	3-11
Figure 3-10. Default/Hold Last State Configuration Parameters for BIU Inputs	3-12
Figure 3-11. Group Data Move Example	3-18
Figure 3-12. Group Data Move Configuration Process	3-23
Figure 3-13. BIU Sweep Sequence	3-24
Figure 3-14. Configuring Sweeps for Data Move Groups	3-25
Figure 4-1. Bit Map for Hold Last State Default Byte	4-9
Figure 5-1. Micro Field Processor Synchronous Sweep	5-2
Figure 5-2. Programmer Communications Window Flow Chart	5-4
Figure 5-3. Power-up Decision Sequence	5-9

Table 1-1. Ordering Information	1-7
Table 1-2. Physical and Functional Characteristics[.....	1-7
Table 1-3. Power Requirements	1-7
Table 1-4. Memory Allocation	1-8
Table 2-1. Power-up Sequence Troubleshooting	2-4
Table 2-2. RS-422 15-Pin Connector Pin Assignments	2-9
Table 3-1. MFP Default Configuration File	3-1
Table 4-1. MFP Configuration Parameters	4-2
Table 4-2. Slot Assignments for HHP Functions	4-4
Table 4-3. Format for Stop/NoI/O Datagram	4-7
Table 4-4. Datagrams Sent from PLC to BIU	4-7
Table 4-5. Format for Write Configuration Datagram	4-8
Table 5-1. Sweep Time Contributions	5-3
Table 5-2. BIU and MFP Mode Correlation	5-5
Table 5-3. Memory Data Types	5-6
Table 6-1. Power-up Diagnostic LED Blink Error Codes	6-2
Table 6-2. Fault Actions	6-4
Table 6-3. Fault Summary	6-4
Table 6-4. Fault References	6-6
Table 6-5. Configuration File Format	6-8
Table 6-6. MFP CPU Software Faults	6-9
Table 6-7. Range and Size of User References for the MFP	A-6
Table C-1. Example Configuration File	C-1

Chapter 1

Introduction

The Series 90 Micro Field Processor (MFP), shown in Figure 1-1, is a specialized Micro PLC that provides local input/output logic within a Field Control station.

Field Control is a family of modular distributed I/O and control products. A basic Field Control station consists of a Bus Interface Unit (IC670GBI002) and up to eight modules. A Field Control station that includes an MFP can support up to seven I/O modules. Figures 1-2 and 1-3 provide an overview of MFP operation in a Field Control station.

MFP features include:

- Compatibility with Logicmaster 90-30/20/Micro programming software (release 6.0)
- Full support for the 90-30 Hand-Held Programmer (HHP)
- An alarm processor function
- Password protection to limit access to PLC contents
- A built-in communications port that supports Series 90 protocols (SNP and SNPX)




Figure 1-1. Series 90 Micro Field Processor




Figure 1-2. Field Control Station Block Diagram




Figure 1-3. Overview of MFP Interaction with the BIU

For more information about Field Control systems, refer to:

Genius® Bus Interface Unit User's Manual (GFK-0825)

Field Control I/O Modules User's Manual (GFK-0826)

Compatibility

- Logicmaster 90-30/20/Micro software: release 6.0 (IC641SWP301L, 304J, 306E, 307F) or later
- Series 90-30 firmware release 6.0
- Series 90-30 Hand-Held Programmer (IC693PRG300)
- Series 90 Protocol (SNP) communications
- BIU firmware release 2.0

Instructions and function blocks

The MFP supports most 90-30 instruction functions and function blocks. Detailed descriptions and examples of the use of these instructions can be found in:

Logicmaster 90-30/20/Micro Programming Software User's Manual (GFK-0466)

Series 90-30/90-20 Programmable Controllers Reference Manual (GFK-0467)

Series 90-30 and 90-20 Hand-Held Programmer User's Manual (GFK-0402)

See Appendix A of this manual for a summary of instructions supported by the MFP.

Functional Description

The MFP contains a CPU circuit board and backplane communications circuitry. The MFP sends and receives data to/from the BIU through the MFP backplane on the CPU and the I/O terminal block backplane.

CPU Board

A block diagram of the functions performed by the CPU board is presented in Figure 1-4.

CPU

The CPU executes and contains the user program and communicates with the programmer (Hand-Held Programmer or computer running Logicmaster 90-30/90-20/Micro software). The CPU sends and receives data through the I/O terminal block backplane, using Field Control communication protocol.

The primary capabilities of the CPU are:

- H8/3003 microprocessor running at 9.84 Mhz
- 256K x 16 sector flash memory for operating system and nonvolatile user program storage (6K words of user flash memory)
- 128 Kbyte super cap backed RAM
- Interrupt for power fail warning (2.0 ms)
- Powerup reset circuit
- Maximum User Program - 6K words
- Registers - 2K words
- Internal Coils - 1024
- Typical Scan Rate - 1.0ms/K of logic (Boolean contacts)

Super Cap Backup for RAM Memory

The capacitor used to maintain the contents of the CMOS RAM memory in the CPU provides data retention for three to four days with the power off at 25°C (77°F).

Interface Connectors

Field Control Connector

The MFP uses a standard Field Control connector that plugs into an I/O Terminal Block. The I/O Terminal Block provides backplane communications between the BIU and I/O devices, including the MFP.

CPU Serial Port

A 15 pin D-type, female connector on the side of the MFP provides the connection to an RS-422 compatible serial port which is used to communicate with Logicmaster 90-30/20/Micro software, the Hand-Held Programmer or for general purpose communications using the Series 90 Protocol (SNP). For more information, see "Connecting a Programming Device" in Chapter 2.

Status Indicators

The module contains four LEDs that provide the user with a visual indication of the CPU and I/O status.

Name	Function
PWR	Lighted if power is supplied to the unit and the power supply is operating correctly. Not lighted if a power supply fault occurs or if power is not applied.
OK	Blinks during self-diagnostics. Blinks (with RUN indicator) if a fault is detected during self-diagnostics. When lighted steadily, indicates that self diagnostics have all passed.
RUN	Lighted when the PLC is executing the logic program entered by the user (RUN mode). Blinks if a fault is detected during self-diagnostics.
COMM	Blinks during communication on the SNP port.




Figure 1-4. Micro Field Processor Functional Block Diagram

Configuration and Programming

Two types of configuration are required for the MFP to operate in a Field Control system: The BIU must be configured to recognize the MFP as a Field Control module, and the MFP internal parameters must be configured.

BIU Configuration

The BIU can be configured using a Hand-Held Monitor (HHM). See Chapter 3 for details.

For information pertaining to use of hand-held devices, refer to the *Series 90™ -30 and 90-20 PLC Hand-Held Programmer User's Manual* (GFK-0402) and the *Genius® Hand-Held Monitor User's Guide* (GFK-0121).

MFP Configuration

The MFP can be configured and programmed using any of the following methods (see Chapter 4 for details):

- Logicmaster 90-30/20/Micro software on one of the following types of computers (you need at least 4 megabytes of hard disk space):
 - Workmaster II or CIMSTAR I industrial computer
 - IBM® PC-ATPS/2® (Personal System 2®) with 2M byte RAM, an Intel® 386 or higher processor, and a hard disk drive
 - MS-DOS compatible Personal Computer with 2M byte RAM, an Intel 386 or higher processor, and a hard disk drive
- Series 90-30/90-20 Hand-Held Programmer (IC693PRG300)
- Reference parameters only can be configured through the BIU. (The BIU is configured using a Hand-held Monitor.)

Both configuration and programming can be accomplished off-line from the PLC, using the Logicmaster 90 programmer. Configuration and programming using the Hand-Held Programmer must be done on-line with the Hand-Held Programmer attached to and interfacing with the MFP.

Use of the programming and configuration software is described in the *Logicmaster 90-30/20/Micro Programming Software User's Manual* (GFK-0466). The Workmaster II computer is described in the *Workmaster II PLC Programming Unit Guide to Operation Manual* GFK-0401. Use of the Hand-Held Programmer is described in the *Series 90-30 and 90-20 PLC Hand-Held Programmer User's Manual* (GFK-0402).

®IBM, Personal System 2 and PS/2 are registered trademarks of International Business Machines Corporation.

Fault Reporting

The MFP monitors internal operations for system and user problems. These faults are reported through the %S references and through an internal fault table. The fault table can be cleared using either the HHP or Logicmaster 90 software.

Access to %S information is available through the Logicmaster 90 software or the Hand-Held Programmer. Data in the %S reference tables is also available to the BIU and can be sent to the network.

For more details on faults and fault reporting, see Chapter 6.

Specifications

Table 1-1. Ordering Information

Description	CatalogNumber
Micro Field Processor	IC670MFP100
Accessories	
Description	CatalogNumbers
Series 90 Micro PLC Programming Software, Cable Kit, and manuals	IC640HWP300
Hand-Held Programmer with Cables and Manual (includes IC693CBL303)	IC693PRG300
Hand-Held Programmer Memory Card	IC693ACC303

Table 1-2. Physical and Functional Characteristics†

Weight	0.35 pounds (0.16kg)
ModuleDimensions	Height: 3.25 inches (8.2 cm) Width: 2.0 inches (5.25 cm) Depth: 2.9 inches (7.3 cm)
Typical Scan Rate	1.0ms/K of logic (Boolean contacts)

† Refer to GFK-0867B, or later for product standards and general specifications.

Table 1-3. Power Requirements

Power is supplied to the MFP from the Field Control backplane. No other power connections are necessary.

Input Voltage	6.5 VDC
Input Current, typical at 24 VDC	with HHP: 300 mA without HHP: 110 mA

Table 1-4. Memory Allocation

Type	Capacity	Contents
User	6K words	ApplicationProgram
%R	2K words	2048registers
%AI	128 words	128 analog inputs
%AQ	128 words	128 analog outputs
%I	512 bits	512 discrete inputs
%Q	512 bits	512 discrete outputs
%G	1280 bits	1280 discrete Genius global data
%M	1024 bits	1024 discrete internal, selectively retentive data
%T	256 bits	256 discrete, internal, nonretentive data
%S	128 bits	128 bits for fault reporting

Chapter 2

Installation

This chapter describes the procedures for installing the MFP in a Field Control station and connecting a programming device.

Minimum Requirements

In order to install and set up the MFP, you will need:

- Series 90 Micro Field Processor (MFP) module
- Programming device (this can be one of the following items)
 - A. Hand-Held Programmer and cable. (Cable must be connected to HHP *before* connecting it to the MFP)
 - B. Logicmaster 90-30/30/Microsoft software, a Workmaster II or CIMSTAR I industrial computer, or an IBM AT, PS/2 or other MS-DOS compatible Personal Computer (with 386 or higher microprocessor and 2 Mbyte memory) and appropriate cables.

If the MFP is to be programmed using Logicmaster 90 software, a Workmaster II, CIMSTAR I, or an IBM or IBM-compatible computer is required to run the software. Logicmaster 90 software can use either a Work Station Interface (WSI) board, an RS-422 port, or a standard RS-232 interface with an RS-422 to RS-232 converter. The WSI board is installed in the Workmaster II computer at the factory.

- Bus Interface Unit (BIU) and Field Control base
- Hand-Held Monitor (IC660HHM501) version 4.7 or later for configuring the BIU

Unpacking


1. **Visual inspection.** Upon receiving your MFP, carefully inspect all shipping containers for damage that may have occurred during shipping. If any part of the system is damaged, notify the carrier immediately. The damaged shipping container should be saved as evidence for inspection by the carrier.

It is your responsibility to register a claim with the carrier for damage incurred during shipment. GE Fanuc will fully cooperate with you, if such action is necessary.

2. **Unpacking.** Unpack all shipping cartons and verify the contents. All shipping containers and packing material should be saved in case it is necessary to transport or ship any part of the system.
3. **Pre-installation Check.** After unpacking the MFP, record all serial numbers. These serial numbers may be required if you need to request product service during the warranty period of the equipment.

Installation


The MFP must be installed on a Field Control Terminal Block, which is mounted on a 35mm x 7.5mm DIN rail. The Field Control station (also called a “stick” because the modules are mounted next to each other on the same DIN rail) can be mounted in any orientation. As shown below, the BIU must be mounted at either end of the stick. The MFP can be mounted in any slot on the stick, other than that occupied by the BIU.



Grounding Procedures

All components of a control system and the devices it controls must be properly grounded. Ground conductors should be connected in a star fashion, with all branches routed to a central earth ground point as shown below. This ensures that no ground conductor carries current from any other branch.

Refer to the *Genius® Bus Interface Unit User’s Manual (GFK-0825)* for complete information about installation and grounding.



Logicmaster Programming Device Grounding

For proper operation, the programmer for Logicmaster 90 Micro software (Workmaster II or CIMSTAR I, or IBM-PC or compatible computer) must have a ground connection in common with the MFP. Normally, this common ground connection is provided by ensuring that the programmer’s power cord is connected to the same power source (with the same ground reference point) as the Field Control station, however this will need to be verified for each installation.

Mounting the MFP on a Terminal Block

Warning

For personal safety, avoid contact with module wiring and with the exposed connectors on the Terminal Block when installing or removing Field Control modules.

Caution


Electrostatic discharge can damage the MFP when it is not installed on a Terminal Block. Always observe good ESD protection practices when handling an un-installed module.

Caution


Do not insert or remove the MFP during operation if the temporarily incorrect data that may result could cause hazardous or unexpected conditions.

1. If the protective label is still in place on the Terminal Block, remove it before attempting to install the MFP.
2. Before installing the MFP, remove the cable slot knockout(s) wherever the module would cover the terminal board connecting cables. The knockout can be removed with pliers, or by pressing *out* from inside the module housing.
3. To install the MFP, position the module so that the cable slot in the module housing is over the connecting cable. Press the module down firmly.
4. If you feel resistance, remove the module and remove any obstruction. Also be sure the connecting cable is seated in the cable slot.
5. After placing the MFP onto the base, tighten its bolts to secure it. The maximum recommended torque is 9 in./lbs.

46416



46417



Power-up Self-test

When power is applied to the MFP through the Field Control Terminal Block, the MFP automatically performs its power-up sequence, which includes self-diagnostics. You should observe the power-up sequence to verify that the unit is installed and operating correctly.

Normal Power-up Sequence

- The Power indicator, labeled PWR, should light.
- The CPU status indicator, labeled OK, blinks during the power-up self diagnostics. When self-diagnostics have been successfully completed, the OK indicator will remain lighted.
- The CPU status indicator, labeled RUN, should light if the unit is configured to run on power-up.
- The COMM indicator does not light until communication is established with an external SNP device.

After verifying that a valid power-up sequence has occurred, attach a programming device (Hand-Held Programmer or computer with Logicmaster 90 Micro software) to configure the MFP and develop programs for the unit.

Error Detection And Correction

If the MFP fails the power-up self-test, one of the conditions listed in Table 2-1 will be observed after applying power.

Table 2-1. Power-up Sequence Troubleshooting

Symptom	Action
PWR indicator does not light.	<ol style="list-style-type: none"> 1. Check that the Field Control station power source is on. 2. With power supply off, make sure that MFP is installed properly on the Terminal Block.
PWR indicator lighted but OK indicator is not lighted.	<p>(This indicates that the power source is good and that the CPU has detected an internal fault.)</p> <p>Refer to Chapter 6, "Diagnostics".</p>
PWR indicator on; OK and RUN indicators are blinking.	<p>Refer to Chapter 6, "Diagnostics".</p> <p>Note: The MFP provides built-in blink codes to assist in troubleshooting. Refer to Chapter 6.</p>
PWR indicator on; OK and RUN indicators are blinking synchronously	<p>Valid system software is not present in flash memory and must be restored using the software update utility.</p>

Connecting a Programming Device

The MFP can be programmed and configured using either the Hand-Held programmer or the Logicmaster 90 software (included in IC640HWP300). Both of these methods are described in Chapter 4.

Connecting the Hand-Held Programmer

Note

The Hand-Held Programmer or RS-422 to RS-232 Converter should not be connected continuously at ambient temperatures above 55°C (131°F).

The Hand-Held Programmer (IC693PRG300) is a compact programming device that connects to the MFP 15-pin serial port through a 6 foot (2 meter) cable that conforms to the RS-485 specification.




Figure 2-1. Hand-Held Programmer

Warning

Always connect the cable to the Hand-Held Programmer first, then connect the cable to the MFP. This avoids any chance of shorting the +5 volt supply on the MFP which could cause incorrect operation of the MFP. Incorrect operation of the MFP could damage the equipment or cause personal injury to an operator.

To connect the Hand-Held Programmer cable for the first time:

- Attach the 15-pin male D connector on one end to the mating 15-pin female D connector on the Hand-Held Programmer.
- Attach the connector on the other end of the cable to the 15-pin female connector on the MFP. These connections are shown in the following figure.




Figure 2-2. Hand-Held Programmer Cable Connection to a Micro Field Processor

Connections for Using Logicmaster 90 Software

You need a Software and Cable Kit package (IC640HWP300) to use Logicmaster 90 Micro software with the MFP.

Workmaster II Computer with WSI

The cable connection for this configuration is from the connector on the WSI board (IC647WMI920) to the MFP serial port as shown below.




Figure 2-3. Logicmaster 90 Programmer to MFP Connection through a WSI

IBM-PC Compatible Computer

This configuration uses a standard RS-422 or RS-232 serial communications port on the IBM-PC compatible computer. An RS-422/RS-232 converter (IC690ACC901) is required. Examples of cable connections for this type of interface are shown below.




Figure 2-4. Examples of Serial Connection from Computer to MFP

Table 2-2. RS-422 15-Pin Connector Pin Assignments

Pin	Signal Name
1	Shield
6	RTS (A)
7	OV
8	CTS (B)
9	RT
10	RD (A)
11	RD (B)
12	SD (A)
13	SD (B)
14	RTS (B)
15	CTS (A)

Installing the RS-422 to RS-232 Converter

Caution

The Miniconverter and cables should be installed with the Field Control station powered down.

The Miniconverter Kit (IC690ACC901) consists of an RS-422 (SNP) to RS-232 Miniconverter, a 6 foot (2 meter) serial extension cable, and a 9-pin to 25-pin Converter Plug assembly. The 15-pin SNP port connector on the Miniconverter plugs directly into the serial port connector on the MFP. The 9-pin RS-232 port connector on the Miniconverter connects to an RS-232 compatible device.

When used with an IBM PC-AT, or compatible computer, one end of the extension cable plugs into the Miniconverter's 9-pin serial port connector, the other end plugs into the 9-pin serial port of the computer. When used with a GE Fanuc Workmaster II computer or an IBM PS/2 Personal Computer, the Converter plug (supplied with kit) is required to convert the 9-pin serial port connector on the Miniconverter to the 25-pin serial port connector on the computer.

For more information see the *Series 90-30 Programmable Controller Installation Manual* (GFK-0356).




Figure 2-5. Series 90 SNP to RS-232 Adapter

Chapter 3

BIU Configuration

A Field Control station is configured through the BIU, using a Hand-Held Monitor. BIU configuration includes *communications configuration* and *module configuration*. Communications configuration consists of setting the BIU parameters related to the communications network used by the Field Control station and includes network mapping. Module configuration consists of all other configuration pertaining to the mapping of I/O data and setting specific module parameters. Module configuration is the phase of BIU configuration that directly relates to the MFP.

For more information concerning BIU configuration, refer to the “Operation” and “Station Configuration” chapters in the *Genius® Bus Interface Unit Users Manual* (GFK-0825).

MFP Default Configuration

When the Field Control station is powered up with the MFP installed, the BIU detects the MFP’s presence. If the BIU does not have a valid configuration for the MFP, it obtains a default configuration from the MFP. The MFP creates a default configuration at power up. This default configuration will be replaced with the new configuration that will be created when you configure the BIU. An example configuration file for the MFP is provided in Appendix C.

Table 3-1. MFP Default Configuration File

Direction	Segment Selector	Offset	Length
MFP ->BIU	%Q	next available reference	0
MFP ->BIU	%AQ	next available reference	0
BIU ->MFP	%I	next available reference	0
BIU ->MFP	%AI	next available reference	0

I/O Mapping Overview

The I/O function of the MFP is configured by the BIU, which sends a configuration file to the MFP. The configuration file contains I/O type and length data that maps BIU reference parameters to input/output tables in MFP memory. The configuration file can be created using the Hand-Held Monitor or using a Genius WRITE CONFIGURATION datagram. (Datagrams, which are messages used by devices on a bus, are discussed on page 4-7.)

The BIU has %I, %AI, %Q, and %AQ internal memories that are used for I/O data. The following table lists the amount of memory of each type that can be transferred to the controller CPU across the network, and the highest address that can be used for each reference type.

I/O Table in BIU	Memory Type	Purpose	Maximum Transferred	Highest Available Reference Address
FROM_NET_DISC	%I	discreteinputs	1024bits	65535
FROM_NET_WORD	%AI	analoginputs	up to 64 words	65535
TO_NET-DISC	%Q	discreteoutputs	1024bits	9999
TO_NET_WORD	%AQ	analogoutputs	up to 64 words	9999

Individual I/O modules, including the MFP, can be configured anywhere within available BIU memory. If a module is to exchange data with the CPU, the module must be placed inside the configured I/O map. Any I/O modules (or portions of modules) configured outside the I/O map will be scanned by the Bus Interface Unit, but the data will not be derived from or supplied to the CPU.

Data in the MFP I/O tables can be mapped to the BIU's four I/O tables using either of two methods: *reference parameters* (see the following discussion) or *group data moves* (see page 3-18). Both of these methods include Default/Hold Last State configuration, which is discussed on page 3-10.

Reference Parameters Overview

For each reference parameter, you can configure:

- Segment selector – which BIU table
- Length – how many bits (discrete data) or words (analog data) to move to or from the MFP to the corresponding table in the BIU.
- Start address (offset) – starting address within the BIU table that the data is being written to or read from

The BIU's four reference parameters are associated with the four I/O tables in the MFP as follows:

BIU Reference Parameter	I/O Table in MFP
1 (discrete inputs)	%Q (discrete outputs)
2 (analog inputs)	%AQ (analog outputs)
3 (discrete outputs)	%I (discrete inputs)
4 (analog outputs)	%AI (analog inputs)

The reference parameters operate in a manner similar to the data Move functions in ladder logic programming. Move function blocks are used to describe the operation of the reference parameters in Figure 3-1. For details on Move function blocks, see the *Series 90™ -30/90-20 Programmable Controllers Reference Manual (GFK-0467)*.




Figure 3-1. BIU Reference Parameters Described as Data Move Function Blocks

Reference Parameter Examples

Example 1 **Local MFP control of station outputs using station inputs as inputs to the MFP:**
Outputs from the MFP directly control station outputs. No inputs or outputs are mapped to the network. In this mode, the MFP, in conjunction with the BIU station, functions as a stand-alone PLC.




Figure 3-2. Reference Parameter Mapping for Example 1




Figure 3-3. Move Function Blocks for Example 1

Example 2 Local MFP control of station outputs using control inputs from the network and from local discrete inputs: Outputs from the MFP control station outputs and are sent back to the network as inputs to the system controller.




Figure 3-4. Reference Parameter Mapping for Example 2




Figure 3-5. Move Function Blocks for Example 2

Example 3 Local MFP control of station outputs with network backup: MFP-solved outputs from local inputs control the station outputs. If the MFP fails, the network outputs will control the station outputs.




Figure 3-6. Reference Parameter Mapping for Example 3




Figure 3-7. Move Function Blocks for Example 3

Default/Hold Last State Configuration Overview

The BIU default/hold last state configuration determines what will happen to MFP data if network communications or communication between the MFP and the BIU is lost.

Network Mapping

The BIU contains four internal tables that are used to send data onto the system network and receive data from the network:

- TO_NET_WORD – word data going out on the network from the Field Control station (%AI)
- TO_NET_DISC – bit data going out on the network from the Field Control station (%I)
- FROM_NET_WORD – word data coming from the network into the Field Control station (%AQ)
- FROM_NET_DISC – bit data coming from the network into the Field Control station (%Q)

BIU Outputs

The output default/hold last state configuration parameters apply to any data sent to the MFP by the BIU, where the ultimate source of that data is the communication network. One parameter applies to the FROM_NET_DISC table. The other applies to the FROM_NET_WORD table. These parameters specify what data to send to the MFP when the network communications are not operating. *Hold last state* indicates send the last valid data received from the network. *Default* means send all zeros to the module. The value of these parameters at powerup is *default*.




Figure 3-8. Default/Hold Last State Configuration Parameters for BIU Outputs

If data from a FROM_NET table is sent to the MFP, but the source of that data is not the network, the parameter does not apply, as shown in Figure 3-9. Also, if no data is sent from a FROM_NET table to the MFP, the parameter for that table will not be needed.




Figure 3-9. Case Where Default/Hold Last State Parameter Does Not Apply

BIU Inputs

There are two input default/hold last state configuration parameters (one for each BIU input table). These parameters specify to the BIU what to put in the tables when the MFP fails, is in stop-faulted mode, or is not present, in place of the data that would be normally read from the MFP. At powerup, this parameter is set to default and the default values are *off*. When the MFP is in stop mode, it always sets to 0 the data read by the BIU.





Figure 3-10. Default/Hold Last State Configuration Parameters for BIU Inputs

How to Configure Reference Parameters


HHM Screen Elements

If reference parameters for the MFP have not been configured, the initial screen you see for each reference parameter will indicate that it is not assigned. For example, when you access the screen for reference parameter 4 (%AI) the following screen will appear.



- In the top line of the screen, **S:1** indicates slot 1 in the Field Control station. (The MFP can be installed in any slot except for the one occupied by the BIU, which is always in slot 0.) **MFP AI** identifies the reference parameter that the screen is displaying (%AI) within the MFP.
- In the second line, **unassigned** indicates that this reference parameter is not assigned.
- The abbreviations at the bottom of the screen indicate the functions assigned to keys **F1** through **F4** for this screen. The **<** and **>** arrows on the screen indicate that you can move to the previous or next parameter. Pressing **F3** (**chg**) allows you to toggle through the BIU table selectors. After editing the reference parameter assignment, you must press **F4** (**entr**) for the change to take place.

If reference parameters have been assigned for the MFP, you will see a screen similar to the following for each reference parameter.



- In the first line, **AQ:008** indicates that 8 words of data in the BIU's AQ table has been assigned to the AI table in the MFP.
- In the second line, **%AQ00001 - 00008** indicates the range of references in the BIU tables that is assigned to begin at AI001 in the MFP.

For information pertaining to the use of hand-held devices, refer to the *Series 90™ -30 and 90-20 PLC Hand-Held Programmer User's Manual* (GFK-0402) and the *Genius® Hand-Held Monitor User's Guide* (GFK-0121).

Sample Screen Sequence for Reference Parameters

In this example, the MFP is installed in slot 1 of the Field Control station. The MFP can be installed in any slot other than that occupied by the BIU (slot 0).

1. Configure the BIU I/O mapping. (Refer to the *Genius® Bus Interface Unit Users Manual* – GFK-0825 for this procedure). (The Sync Module screen will be the final screen in this process before you proceed to the individual module configuration screens.) If reference parameters have not been assigned for the MFP, the first screen you will see for MFP configuration will appear as follows.

```
S:1          EMPTY
< >        tgl read
```

2. Press the **read** function key (**F4**) to read slot 1. The following screen will appear.

```
S:1          MFP1.0
< >        del zoom
```

3. To begin assigning reference parameters, press the zoom key (**F4**). The following screen, which shows the first table (discrete outputs) selected, will appear.

```
S:1 MFPQ1
Unassigned
< >        chg entr
```

- 4. Configure BIU table, length, and offset (Ref Addr) for the selected table in the MFP.
 - A. To assign the reference parameter, press the **chg** key (**F3**). The following screen will appear.

```
S:1 MFPQ1 I
Select table

      tgl entr
```

- B. To toggle through the allowed BIU tables, press **F3**. When you have selected the table you want to map the first MFP reference parameter to, press the **entr** key (**F4**). The following screen will appear.

```
S:1 MFPQ1 I:000
Select length

      clr entr
```

- C. Enter the length, using the numeric keys on the HHM keypad. The length you enter will be in bits if the table selector is a discrete table and in words if the table selector is an analog table. If you enter a length that is not on a byte boundary (a multiple of 8) for discrete data, the BIU will round down to the nearest correct offset.

To accept the length you have entered, press the **entr** key (**F4**). (If you have not entered a value for length, the reference parameter will remain unassigned.) A screen that shows the default (next available) reference address will appear.

```
S:1 MFPQ1 I:008
Ref Addr 00001

      clr entr
```

- D. To change the default reference address, use the numeric keys. To accept the reference parameter assignment, press the **entr** key (**F4**). The message, **PLEASEWAIT**, will be displayed, followed by the screen shown below.

```

S:1 MFPQ1 I:008
      I00001-00008
< >      chg entr

```

- E. The first reference parameter has now been configured. To go to the next reference parameter (MFPAQ), press **F2**.
5. Repeat steps 4A through 4E for the remaining reference parameters. As you press the **>** key (**F2**), Reference parameters are displayed in the following order: Q1, AQ, I1, and AI.
 6. When you have assigned the final reference parameter, press **F2** to go to the first Default/Hold Last State screen.

Screen Sequence for Default/Hold Last State Configuration

1. Note that you will see Default/Hold Last State screens only for tables that have a configured reference parameter. If a reference parameter is unassigned, the corresponding Default/Hold Last State screen will not be displayed.

```

S:1 Module-> %I
      DEFAULT:ZERO
< >      tgl entr

```

When **DEFAULT** is set to **ZERO**, all zeros will be sent if communication is lost. When **DEFAULT** is set to **HOLD**, the last valid data received will be sent.

2. To change the default setting, press **F3** and then accept the change by pressing **F4**. To go to the next screen, press **F2**. By pressing **F2**, you can toggle through the Default/Hold Last State parameters in the following order:

```

Module -> %I
Module -> %AI
Network -> %AQ
Network -> %Q

```

When you have finished configuring the Default/Hold Last State parameters, BIU configuration for the MFP is complete. When the MFP accepts the new reference parameter and default/hold last state configuration from the BIU, it updates its copy of the configuration file to reflect the new values. The BIU then builds a scanning structure that includes the MFP.

Error Messages for Reference Parameters

- If you enter an invalid length value, the HHM will display the following screen. If this happens, press the **C**lear key to return to the “Select length” screen.

```
S:1 MFPQ1 I:612
bad length err
exit
```

- If you assign a reference parameter length and offset so that it overlaps an assignment in the BIU for another input module, a bad ref address message will be displayed. This screen will also be displayed if you enter an offset that is not within the boundaries of the selected table. Press the **C**lear key to reassign the reference parameter.

```
S:1 MFPQ1 I:504
bad ref address
exit
```

If the module rejects the configuration, the BIU and the MFP will return to the original configuration state. The HHM will show the following screen. If this happens, press the **c**lear key. The HHM will return the display to the original configuration.

```
S:1 MFPQ1 I:504
cfg rejected
exit
```

Group Data Moves Overview

Group data moves provide an alternate means of mapping MFP I/O tables to I/O tables in the BIU. Up to four types of data in the MFP can be moved by defining a single Group. You can configure up to 16 Group data moves.

Groups differ from reference parameters in the following ways:

- The data within the MFP does not have to be mapped to a table within the BIU, but can be mapped directly to another smart module.
- The data within the MFP can be mapped with an offset.
- The data moved can be scanned selectively. It does not have to be scanned every input or output scan of the BIU.

A Group data move can be thought of as a super move that contains from one to four individual Moves, as shown in Figure 3-11. Note that bit data can be moved to word data areas, and vice versa.

- Each Group data move has a source slot and a destination slot, either of which can be slot 0. Slot 0 represents the BIU's internal tables.
- The Moves inside the Group can be from any table inside the source to any table inside the destination.
- The following data types within the MFP module are bidirectional. That is, they can be read from or written to by the BIU: R, AI, AQ, A, I, Q, M, T, G.
- The tables S, SA, SB, and SC have MFP to BIU direction only. The BIU only has read access to these tables.





Figure 3-11. Group Data Move Example

How to Configure Group Data Moves


Five parameters are configured for each Move within the Group data move: source slot, destination slot, source reference, destination reference, and byte length. In addition, move defaults and selective sweeping for a cycle of sixteen sweeps can be defined for each Move.

Screen Sequence for Configuring Groups


1. To configure data Groups, begin at the main menu for the BIU:



2. Press **F2** to select the **Configuration** option. The following screen will be displayed:



3. Press the **more** function key (**F4**). The following screen will be displayed:




- 4. Press **F1** to select **Grp Data Move**. The first data Group move screen will be displayed. On this screen, each of the 16 potential data Groups is represented by a letter N (no Moves defined for that Group) or Y (at least one Move is defined for that Group). The number of the data Group indicated by the cursor appears in the upper right corner of the screen.



- 5. To set up a Group move, place the cursor under the number of the Group and press the **zoom** function key (**F4**). The configuration screen for the first parameter, the source slot, will be displayed.

A. Configure parameter 1 – Source Slot.

Enter the slot number of the module that will be the source of the data (0 for the BIU, 1 to 8 for the MFP). The BIU will verify that a smart module is configured in the selected slot.




Define the source slot of the Group data move.
Default: 0
Valid keystrokes: numeric 0– 8, previous parameter (<), next parameter (>), accept parameter (**entr**), up arrow

Press **F4** (enter) to accept the slot. Press **F2** (>) to go to the next configuration screen.

B. Configure parameter 2 – Destination Slot

Enter the slot number of the module that will receive the data (0 for the BIU, 1 to 8 for the MFP). The destination module can be the same as the source module. The BIU will verify that a smart module is configured in the selected slot.



Define the destination slot of the Group data move.
Default: 0
Valid keystrokes: numeric 0–8, previous parameter, next parameter, enter parameter, up arrow

Press **F4** (enter) to accept the destination slot. Press **F2** (>) to go to the next configuration screen.

C. Configure parameter 3 – Move 1 Source Reference

For each data type, a starting offset and length can be specified.

To select a table type, press the **F3** (tgl) key to toggle through the list of valid table types for the MFP. The following data types can be read or written: R, AI, AQ, A, I, Q, M, T, G. In addition, S, SA, SB, and SC data can be moved from the MFP to the BIU. (The BIU has read access only to S, SA, SB, and SC tables.) To enter the start address within the table, use the numeric keys.

Press **F4** (enter) to accept the source reference. Press **F2** (>) to go to the next configuration screen.

```
Group Move      1:1
Src Ref:%AI0009
< >          tgl entr
```

Define the source reference for the first Group of data to be moved.

Valid keystrokes: tgl, numeric, previous parameter, next parameter, enter, up arrow

D. Configure parameter 4 – Move 1 Destination Reference

To configure the destination reference, enter the table selection and the starting address within the table. Press **F3** to toggle through the table types. To enter the start address within the table, use the numeric keys.

Press **F4** (enter) to accept the destination reference. Press **F2** (>) to go to the next configuration screen.

```
Group Move      1:1
Des Ref:%R0001
< >          tgl entr
```


Define the destination reference for the first Group of data to be moved.

Valid keystrokes: tgl, numeric, previous parameter, next parameter, enter, up arrow

E. Configure parameter 5 – Move 1 Byte Length

This screen defines the number of bytes to be moved from the source to the destination. The BIU will insure that the value is valid for the source slot and the destination slot.

Press **F4** (enter) to accept the length you have specified. Press **F2** (>) to go to the next configuration screen.




Define the byte length of the Group of data to be moved.

Valid keystrokes: numeric, previous parameter, next parameter, up arrow

6. When you have finished entering the parameters for the first Move in the Group press **F2** (>) to go to the next Move. Up to four moves can be configured for a Group.

When all four Moves in a Group are configured, the Move Deflt (Move Default) screen will be displayed.

How to Configure Default/Hold Last State for Group Moves



Define the default values (0 or hold last state) the BIU will send to the MFP if network communications are lost.

Valid keystrokes: previous, next, tgl, entr

The Move Deflt screen allows you to select the default values that the BIU will send to the MFP if the BIU loses communication with the module that is the source of the data.

You will be able to change the setting (Y or N) in the Move Default screen for a Move with a source slot of 0 only if the following conditions are met:

- data type is Q or AQ,
- data is included in the BIU's configured I/O map

1. To select the default for a Move, place the cursor under the selection for each Move (Move 1 of Group 1 in the example above). Press **F3** (tgl) to select either Y (default to 0) or N (hold last state).
2. Press **F4** (enter) to accept the configuration. Press **F2** (>) to go to the next configuration screen, which will be the Sweep Enab screen for configuring selective sweeps.

An overview of the configuration process for a Group data move is shown in Figure 3-12. The procedure for configuring selective sweeps is explained on page 3-24.




Figure 3-12. Group Data Move Configuration Process

How to Configure Selective Scanning of Group Data Moves

There are 16 individually programmable sweeps within the BIU. An important characteristic of Group Data is that it does not have to be moved during each BIU sweep. By configuring a Group to be selectively scanned by the BIU, you can decrease the overall average sweep time of the BIU. The last step in configuring a Group is to specify the BIU sweeps during which the data should be moved.

The BIU sweep sequence is illustrated in Figure 3-13. Using the HHM, a Group can be programmed to be scanned on any one or more of the 16 sweeps.





Figure 3-13. BIU Sweep Sequence

In the Sweep Enab screen, shown, in Figure 3-8, the selective sweep configuration for a Group is represented as a 16-bit word with each bit in the word representing a sweep. (Bit 0 corresponds to sweep 1.) A Y in a bit position indicates that this Group will be scanned in the corresponding sweep. To configure sweeps, press the left or right arrow keys to move to each bit in the word and press **F3** to toggle between Y (yes) and N (no).


After completing this screen, press **F4** (entr) to save the configuration. This procedure completes the configuration of a Group. To return to the Group screen, press the **Clear** key or **F1** (<).



Select whether Group data will be sent during each BIU sweep.
The number **02:01** in this example represents Group 2:BIU sweep 1.
Default: **Y**
Valid keystrokes: previous, next, tgl, entr, clr

Figure 3-14. Configuring Sweeps for Data Move Groups

In the screen below, the Y indicates that at least one Move for the first Group has been defined. Up to four moves can be configured for a Group.



Chapter 4

MFP Configuration

MFP internal functions can be configured using Logicmaster 90-30/20/Micro software or a Series 90-30/90-20 Hand-Held Programmer. The configurable parameters for these functions are listed in Table 4-1.

Both configuration and programming can be done off-line from the MFP, using the Logicmaster 90 software. Configuration and programming using the Hand-Held Programmer must be done with the Hand-Held Programmer (HHP) attached to and interfacing with the MFP.

For more information about the use of these programmers, refer to:

Logicmaster 90-30/20/Micro Programming Software User's Manual (GFK-0466)

Series 90-30/90-20 Programmable Controllers Reference Manual (GFK-0467)

Workmaster II PLC Programming Unit Guide to Operation Manual (GFK-0401)

Series 90-30 and 90-20 PLC Hand-Held Programmer User's Manual (GFK-0402)

Table 4-1. MFP Configuration Parameters

Parameter	Description	Possible Values	Default Value
I/O Scan-Stop	Determines whether I/O is to be scanned while the MFP is in STOP mode	YES NO	NO
Pwr Up Mode	Selects powerup mode.	LAST STOP RUN	LAST
Cfg From	Source of configuration when the MFP is powered up. (Logic source is always flash memory.)	RAM PROM (flash memory)	RAM
Registers	Selects source of register data when the MFP is powered up.	RAM PROM (flash memory)	RAM
Passwords	Determines whether the password feature is enabled or disabled. (Note: If passwords are disabled, the only way to re-enable them is to clear the MFP memory by power cycling the unit and pressing the appropriate keys on the HHP.) See page 4-5.	ENABLED DISABLED	ENABLED
Baud Rate	SNP Port data transmission rate (in bits per second).	300 4800 600 9600 1200 19200 2400	19200
Data Bits	Determines whether the CPU recognizes 7-bit or 8-bit words (SNP requires 8 bits.)	7 8	8
Parity	Determines whether parity is added to words	ODD EVEN NONE	ODD
Stop Bits	Number of stop bits used in transmission. (Most serial devices use one stop bit; slower devices use two.)	1 2	1
Modem TT	Modem turnaround time (10ms/unit) This is the time required for the modem to start data transmission after receiving the transmit request.	0-255	0
Idle Time	Time (in seconds) the CPU waits for the next message to be received from the programming device before it assumes that the programming device has failed and proceeds to its base state	1-60	10
Sweep Mode	Normal - the sweep runs until it is complete Constant - the sweep runs for the time specified in Sweep Tmr	NORMAL CNST SWP	NORMAL
Sweep Tmr	Constant sweep time (in milliseconds). Editable when Sweep Mode is CNST SWP; non-editable otherwise.	NORMAL mode: N/A CNST SWP mode: 5- 200	N/A 100


Using the HHP to Configure and Program the MFP

You can use the HHP to perform the following tasks:

- *Statement List* logic program development. The Statement List programming instructions provide basic (boolean) instructions to execute logical operations such as AND and OR, and many functions that execute advanced operations including arithmetic operations, data conversion, and data transfer.
- On-line program changes
- Search logic programs for instructions and/or specific references
- Monitor reference data while viewing logic program
- Monitor reference data in table form in binary, hexadecimal, or decimal formats
- Monitor timer and counter values
- View MFP scan time, firmware revision code and current logic memory use
- Transfer logic and configuration between the Hand-Held Programmer and a removable Memory Card (IC693ACC303). This feature allows programs to be moved between PLCs or loaded into multiple PLCs
- Start or stop the MFP from any mode of operation

HHP Configuration Screens


1. The following screen (Main Menu) will be displayed on the Hand-Held Programmer after the MFP has successfully completed its power-up sequence.



This screen allows you to select the mode of operation of the HHP. The choices are: PROGRAM, DATA, PROTECTION, and CONFIGURATION. (Use the Up and Down cursor keys to scroll the menu selection display.) For information on using these modes refer to the *Series 90-30 and 90-20 PLC Hand-Held Programmer User's Manual* (GFK-0402).

2. Enter the configuration mode by pressing the **4** key then the **ENT** key from the Main Menu screen.

The up and down cursor keys allow you to move between CPU configuration and I/O configuration. The left and right arrows allow selection of parameters within each of the configurations.



The screen shown above shows the first configuration item which allows you to change the Hand-Held Programmer Key Click feature. The default is KEY CLK: OFF. This screen also indicates that the CPU function is located in rack 0 and slot 01 (R0:01). For compatibility with Series 90-30 PLCs, the different functions mimic the rack and slot locations. The MFP module is always in rack 0. The fixed slot assignments for the different functions of the MFP are shown in Table 4-2.

Table 4-2. Slot Assignments for HHP Functions

Slot (as seen on HHP)	Function	Fixed/Configurable
0	Power Supply	Fixed
1	CPU Parameters	Configurable

- Pressing the up arrow key causes the next screen to be displayed.

```

R0:00 PWR SUP <S
I/O BASE:MFP
    
```

- Pressing the down arrow key causes the previous screen (shown below) to be displayed.

```

R0:01 PLC      <S
KEY CLK: OFF
    
```

Use the left and right arrow keys to view the other MFP parameters for configuration and the -/+ key to select the items within each parameter. Acceptable values and default values for MFP parameters are shown in Table 4-1.

Storing the User Program Using the HHP

After editing a program, you must save it in nonvolatile flash memory. To do this, perform the following steps:

- With the HHP showing a screen that resembles the following, press the **WRITE** key.

```

#XXXX      <S
<END OF PROGRAM>
    
```

The following screen will appear.

```

WRITE MEM CARD<S
PRG CFG REG
    
```


- Press the Ç key twice. The following screen will appear.

```

WRITE USR PRG <S
ONLY
    
```

- Press the **ENT** key. This will store the edited user program to non-volatile flash memory. Note that this may take 5 to 10 seconds.

When the program has been stored, the following screen will be displayed. (At this point the program can be put into RUN mode.)



- 4. To return to the program edit mode, press the ENT key.

Storing Configuration and Register Data Using the HHP

Because the user program is stored in non-volatile flash memory, only one copy is maintained, even after you invoke the **Write to EEPROM/FLASH** function in Logicmaster 90, or using the Hand-Held Programmer. However, separate copies of the User Configuration and Reference Tables are maintained in the EEPROM/FLASH areas of the flash memory.

To store the configuration and register data:

- 1. From the END OF PROGRAM screen, press the **WRITE** key (see step 1 on page 4-4.)
- 2. Press the Ç key until the following screen appears.



- 3. Press the **ENT** key. This will store the configuration and register data only. (Program data will not be stored.) When the store operation is complete, the WRITE OK screen will be displayed.
- 4. To return to the edit mode, press the **ENT** key.

Other HHP Functions

Clearing User Memory with the HHP

To clear user RAM (configuration, registers, user program and passwords), power cycle or reset the Field Control station (including the MFP) with the following HHP keys pressed.



To boot up without loading memory from the EEPROM, power cycle or reset the Field Control station with the following HHP keys pressed.



Booting up in Stop Mode without Clearing Memory

Power cycle or reset the Field Control station with the following HHP keys pressed.



Using Logicmaster 90 Software to Configure the MFP

Using the configuration software, which is included as a part of the Logicmaster 90-30/20/Micro software package, you can do the following tasks:

- Specify a name for the system
- Configure CPU parameters
- Archive or save the configuration in a file
- Transfer configurations between the MFP and the programmer

The programming software portion of the Logicmaster 90 software package provides the following capabilities:

- Develop ladder diagram programs off-line
- Monitor and change reference values on-line
- Edit a program on-line
- Transfer programs and configurations between the MFP and programmer
- Store programs and configuration data on disk
- Annotate programs
- Print programs with annotation and/or cross references
- Display help information
- Use symbolic references
- Cut and paste program fragments
- Print programs and configurations on various printers

The MFP parameters are shown in the following configuration screen. Acceptable values, including default values, for these parameters are listed on page 4-2. The *Logicmaster 90-30/20/Micro Programming Software User's Manual* (GFK-0466) provides details on the use of the configuration and programming software.

```

1 2 3 4 5 6 7 8 9 10
>
SERIES 90 MICRO
SOFTWARE CONFIGURATION
Catalog #: IC670MFP100 MICRO FIELD PROCESSOR
-----
IOScan-Stop: NO      Baud Rate : 19200      Data Bits : 8
Pwr Up Mode: LAST   Parity : ODD
Cfg From : RAM      Stop Bits : 1
Registers : RAM     Modem TT : 0          1/100 Second / Count
Passwords : ENABLED Idle Time : 10      Seconds
                               Sweep Mode : NORMAL
                               Sweep Tmr : N/A      msec
-----
C:\LM90\MFP          OFFLINE          PRG: MFP          CONFIG VALID
REPLACE

```

Using Datagrams

Datagrams are messages sent from one device on a bus to one or more other devices on that bus. They can be sent from an application program in the BIU.

For general information about the use of datagrams, refer to :
Genius® I/O System and Communications User's Manual (GEK-90486-1)

For information about the use of datagrams in a Field Control system, refer to:
Field Control™ Distributed I/O and Control System Genius® Bus Interface Unit User's Manual (GFK-0825)

Placing the MFP in Stop/No I/O Mode

The MFP can be placed in the Stop/No I/O mode using the following datagram message from the Genius bus.

Table 4-3. Format for Stop/No I/O Datagram

Byte	Value	Description
0	20 (hex)	Genius function code
1	21 (hex)	Genius sub-function code for TEST message
2	F6 (hex)	GBIU-specific test message code
3	18 (hex)	SEND_A_SEND_TEST_DATA command code
4	slot	slot to send the SEND_TEST_DATA command to
5	0	reserved
6	0	offset of data least significant byte
7	00	offset of data most significant byte
8	04	byte length of data
9	47 (hex)	password byte 1
10	45 (hex)	password byte 2
11	46 (hex)	password byte 3
12	01	put MFP in Stop/No IO mode

Datagrams Used for MFP/BIU Communication

Table 4-4. Datagrams Sent from PLC to BIU

Datagram	Genius Subfunction Code (hex)
WriteConfiguration	04
Begin Packet Sequence	06
End Packet Sequence	07

Note

The Write Configuration datagram must be preceded by a Begin Packet Sequence datagram and followed by an End Packet Sequence datagram.

Table 4-5. Format for Write Configuration Datagram

Byte	Value	Description
0	20 (hex)	Genius function code
1	4	Genius sub-function code for WriteConfiguration
2	1	slot for module (MFP should be slot 1)
3	1F (hex)	Smart Module Id
4	0	reserved
5	4	MFP module Id
6	0	reserved
7	3	reference types (3=inputs and outputs)
8	0	reserved
9	24 (hex)	byte length configuration
10	0	reserved
11	0	reserved
12	0	reserved
13	0	reserved
14	0	reserved
15	0 to 1F	hold last state default byte (see bit map on page 4-9)
16	0	reserved
17	2	number of input reference parameters
18	2	number of output reference parameters
19, 20	0 to 64	byte length number of inputs to BIU from MFP %Q table
21, 22	16, 18, 10, 12	BIU table to put %Q data from MFP, 16=%I, 18=%Q, 10=%AI, 12=%AQ
23, 24	0 to 255	byte offset from start of selected BIU table to put MFP %Q table data
25, 26	0 to 254	byte length of number of inputs to BIU from MFP %AQ table
27, 28	16, 18, 10, 12	BIU table to put %AQ data from MFP, 16=%I, 18=%Q, 10=%AI, 12=%AQ
29, 30	0 to 255	byte offset from start of selected BIU table to put MFP %AQ table
31, 32	0 to 64	byte length of number of outputs from BIU to MFP %I table
33, 34	16, 18, 10, 12	BIU table to get %I data to MFP, 16=%I, 18=%Q, 10=%AI, 12=%AQ
35, 36	0 to 255	byte offset from start of selected BIU table to get MFP %I table data
37, 38	0 to 254	byte length of number of outputs from BIU to MFP %AI table
39, 40	16, 18, 10, 12	BIU table to get %AI data to MFP, 16=%I, 18=%Q, 10=%AI, 12=%AQ
41, 42	0 to 255	byte offset from start of selected BIU table to get MFP %AI table data




Figure 4-1. Bit Map for Hold Last State Default Byte

Chapter 5

System Operation

This chapter describes the operation of the MFP. It includes a discussion of the sweep sequence, power-up and power-down sequences, clocks and timers, system security through password assignment, and the I/O system.

PLC Sweep Summary

The logic program in a PLC executes in a repetitive fashion until stopped by a command from the programmer or by a command from another device, such as a host computer. This repetitive cycle, which includes the sequence of operations necessary to execute a program one time, is called a *sweep*. In addition to executing the logic program, the sweep includes obtaining data from input devices, sending data to output devices, performing internal housekeeping, and servicing the programmer.

The MFP is different from a typical PLC in that it does not perform an I/O scan. This function is performed by the BIU. Therefore, in a Field Control station, the sweep is shared by the BIU and the MFP in a synchronous relationship, as shown in Figure 5-1. Numbers 1-3 in the figure indicate the points in the sweep where the MFP and the BIU are synchronized.

Note that Figure 5-1 shows the processes that occur during a normal sweep. Interrupt-driven processes that could also affect the sweep, such as those initiated by the programmer serial port or backplane driver, are not shown.

The following configuration items affect the MFP sweep:

- I/O Scan-Stop:** Stop with I/O Disabled (**No**)
Stop with I/O Enabled (**Yes**)
- Sweep Mode:** **Normal**
Constant sweep (**CNST SWP**)




Figure 5-1. Micro Field Processor Synchronous Sweep

MFP and BIU Synchronization

Synchronization between the MFP and the BIU occurs at three points in the MFP’s sweep. Synchronization is only necessary when both the MFP and BIU are running (the BIU is scanning I/O). These points of synchronization are marked 1–3 in Figure 5-1.

1. At the beginning of its input scan, the MFP waits for group data from the BIU (if any data groups are defined) and then any data from the BIU defined in reference parameters (if any output reference parameters exist).
2. After receiving the input data from the BIU, the MFP solves its logic program.
3. After solving the logic program, the MFP will wait for the BIU to request data from the MFP defined in reference parameters (if any input reference parameters exist) and then wait for the BIU to request any group data from the MFP (if any data groups are defined).

Sweep Time Contribution

Five items contribute to the sweep time of the MFP (Table 5-1). The sweep time consists of fixed times (housekeeping and diagnostics) and variable times. The lengths of the variable times depend on the duration of interrupt-driven processes, the size of the user program, and the type of programming device connected to the MFP.

Table 5-1. Sweep Time Contributions

Sweep Element	Description	Time Contribution (ms)
Housekeeping	<ul style="list-style-type: none"> • Schedule start of next sweep • Determine mode of next sweep • Update fault reference tables • Reset watchdog timer 	0.260
Data Input	Input data is received from BIU	Determined by BIU
Program Execution	User logic is solved	Execution time depends on the length of the program and the types of instructions used in the program. Appendix B lists instruction execution times.
Data output	Output data is sent to BIU.	Determined by BIU
Communications Services	Service requests from programming device via a serial port interrupt.	Logicmaster 90: 0.108 HHP: 1.14

Normal Sweep Processes

Housekeeping

The housekeeping portion of the sweep performs the tasks necessary to prepare for the start of the sweep. If the MFP is in the constant sweep mode, the sweep will be delayed until the required sweep time elapses. If the required time has already elapsed, the **ov_swp**%SA0002 contact is set and the sweep continues without delay.

Next, the timer values (hundredths, tenths, and seconds) are updated by calculating the difference from the start of the previous sweep and the new sweep time. To maintain accuracy, the actual start of sweep is recorded in 100 microsecond increments. The remainder field of each timer contains the number of 100 microsecond ticks that have occurred since the last time the timer value was incremented.

I/O Scanning

The input and output scan portion of the MFP consists of reading and writing data to a data transfer buffer. The MFP's backplane driver reads and writes information to this buffer.

I/O scanning is configured by the BIU, which sends a configuration file that contains I/O type and length data to the MFP. The MFP sends and receives data to/from the BIU through the backplane on the IO terminal block.

The input and output scans are based on MFP references I1-I512, Q1-Q512, AI1-AI128, and AQ1-A Q128. References used by the host PLC will map to these MFP references. See the *Field Control™ Distributed I/O and Control System Genius® Bus Interface Unit User's Manual* (GFK-0825) for examples of I/O mapping.

Input Scan

If the MFP is in STOP mode and the **I/O Scan-Stop** parameter is configured to NO, the input scan will be skipped. (The BIU could still be scanning I/O.)

Output Scan

If the MFP is in STOP mode and the **I/O Scan-Stop** parameter is configured to **NO**, the output scan will be skipped. (The BIU could still be scanning I/O.)

If the MFP is in STOP mode with I/O scan enabled (**I/O Scan-Stop** configured to **YES**), the scan is executed, but the outputs will hold the states of the most recent scan.

Program Execution

The application program is executed by the microprocessor on the CPU board. The logic solution always begins with the first instruction in the application program immediately following the completion of the input scan. Solving the logic provides a new set of outputs. The logic solution ends when the END instruction is executed.

Many program control capabilities are provided by the Control Functions, which are described in the *Series 90-30/90-20 Programmable Controllers Reference Manual* (GFK-0467) and in the *Hand-Held Programmer User's Manual for Series 90-30/90-20 Programmable Controllers* (GFK-0402). A list of execution times for each programming function can be found in Appendix B of this manual.

Programmer Window

This part of the sweep is dedicated to communicating with the programmer. If there is a programmer attached, the CPU executes the Programmer Communications Window as shown in Figure 5-2. Support is provided for the Hand-Held Programmer (HHP) and for other programmers that can connect to the serial port and use SNP.

The CPU performs one operation for the programmer each sweep, that is, it honors one service request or response to one key press. If the programmer makes a request that requires more than 6 milliseconds to process, the request processing will be spread out over several sweeps so that no sweep is impacted by more than 6 milliseconds.




Figure 5-2. Programmer Communications Window Flow Chart

Deviations from the Standard Program Sweep

The user can select certain deviations from the Standard Program Sweep by configuration or by program instructions. These variations are described in the following paragraphs.

Constant Sweep Time Mode

In the Standard Program Sweep, each sweep executes as quickly as possible with a varying amount of time consumed each sweep. An alternative to this is the *Constant Sweep Time* mode. In the Constant Sweep Time mode, each sweep consumes the same amount of time, which can be selected during configuration to be from 5 to 200 milliseconds. For more information on the constant sweep timer, refer to “Clocks and Timers”.

MFP Sweep When in STOP Mode

When the MFP is in STOP mode, the application program is not executed. In this mode, you can choose whether or not the I/O is scanned, and communications with the programmer will continue. For efficiency, the operating system uses larger time-slice values than those that are typically used in RUN mode (usually about 50 ms per window).

BIU/MFP Mode Correlation

The MFP’s sweep manager always performs housekeeping and programmer window functions regardless of the combination of BIU and MFP modes. The correlation of modes between the BIU and MFP is shown in Table 5-2.

An interrupt from the backplane driver can occur at any point in the MFP sweep as the result of a command from the BIU. When the BIU is in I/O scan mode and the MFP is in Stop-No IO or Stop Fault mode, the data the BIU requests from the MFP will either be defaulted or held last state, depending on the configuration of the MFP.

Table 5-2. BIU and MFP Mode Correlation

BIU Mode	MFP Mode	Resulting MFP Actions
notscanningI/O	stop/nb/O	no additional actions performed
notscanningI/O	stop/I/scan	no additional actions performed
notscanningI/O	running	no additional actions performed
scanningI/O	stopnoI/O	waits for data transfer (BIU to MFP) waits for data transfer (MFP to BIU)
scanningI/O	stop/I/scan	waits for data transfer (BIU to MFP) waits for data transfer (MFP to BIU)
scanningI/O	running	waits for data transfer (BIU to MFP), executes logic waits for data transfer (MFP to BIU)

Software Structure

The Series 90 software structure supports program execution and basic housekeeping tasks such as diagnostic routines, input/output scanners, and alarm processing. The operating system also contains routines for communication with the programmer. These routines provide for the uploading and downloading of application programs, return of status information, and control of the MFP. The application (user logic) program which controls the end process to which the MFP is applied, is called a control program.

Program Structure

Each control program is comprised of a single program block. This includes the user program and some system overhead. The program block must be less than or equal to 6K words.

Data Structure

The MFP has nine data memories, each for a specific purpose. The following table lists these memories.

Table 5-3. Memory Data Types


Memory Type	User Reference	Data Type
Discrete Input	%I	bit
Discrete Output	%Q	bit
Discrete User Internals	%M	bit
Discrete Temporaries	%T	bit
Discrete System	%S	bit
Discrete Global	%G	bit
Register	%R	word
Analog Input	%AI	word
Analog Output	%AQ	word

Note: The % symbol is used to distinguish machine references from nicknames and is only used with Logicmaster 90 software.

Discrete Memory Reference Definitions

Type	Definition	Function
%I	Discrete reference input point	The state of the input as detected during the last input scan
%Q	Discrete reference output point	The state of the output as last set by the application program
%M	User internal	Internal coil used for boolean logic when the result of a rung is only required to be used later in the program as conditional logic
%T	Temporary	Internal coil – similar to %M reference except that it is non-retentive
%S	System discretets (S, SA, SB, SC)	Include system bits used internally by the CPU, fault bits for holding system fault data, and reserved bits for future system expansion
%G	Global	Used to access data shared among PLCs. Always retentive.

User internals (%M) are useful when the coil in a rung is only required to be used later in the logic solution as conditional logic and not outside the PLC. The following example shows %I0012 and %I0016 being used to set user internal %M0005, in a manner similar to the use of a control relay in electromechanical logic.



Temporary references (%T) are *not* saved across a power failure; that is, they are non-retentive. %M and %Q memories are retentive unless used with a “normal” coil, e.g., --()--, which is non-retentive. Retentive memory is backed up by a super cap, which maintains the memory for approximately one week at 25 °C.

System discretets (S, SA, SB, SC) include: *system bits* which are used internally by the CPU, *fault bits* for holding system fault data, and *reserved bits* for future system expansion.

Many of the fault bits are referenced by the application program to determine which faults exist in the MFP. Examples of these fault contacts are over sweep condition (ov_swp), and low battery (low_bat). The first scan contact (fst_scn) also resides here. Refer to Chapter 6 for more information on fault bits.

Transition Bits

Transition bits are discrete memory locations used internally by the MFP when solving logic that involves transitional coils. This data is not accessible to the user. The MFP sets and resets this transition data based upon changes in the associated status table.

Power-Up and Power-Down Sequences

Power-Up Sequence

1. The CPU runs self-diagnostics. This includes checking a portion of RAM to determine whether or not the RAM contains valid data.
2. The CPU creates a default configuration and waits for the BIU to initiate handshaking.
3. BIU-MFP handshaking takes place.
 - A. If the module feature set for the MFP is valid and the revision levels for the BIU and MFP are compatible, the BIU configures the MFP reference parameters.
 - B. If the MFP and the BIU are not compatible, a LOSS OF MODULE fault is generated.
4. In the final portion of the power-up sequence, the mode of the first sweep is determined based on CPU configuration (MFP internal parameters configuration). Figure 5-3 shows the decision sequence followed by the CPU when it decides whether to copy from flash memory or to power-up in STOP or RUN mode. In the figure, text in bold refers to commands entered using the HHP. For details on using the HHP commands listed in the table below, see page 4-5.

Command	HHP Key Combination
clear	Press CLR] and M/T] simultaneously (using HHP)
ld_not	Press LD] and NOT] simultaneously (using HHP)
ostop	Press NOT] and RUN] simultaneously (using HHP)

Power-Down Conditions

System power-down occurs automatically if the power supply detects that incoming AC power has dropped. The minimum hold time is one half cycle.




Figure 5-3. Power-up Decision Sequence

Clocks and Timers

Elapsed Time Clock

The elapsed time clock uses 100 microsecond “ticks” to track the time elapsed since the CPU powered-on. The clock is not retentive across a power failure; it restarts on each power-up. Once per second the hardware interrupts the CPU to enable a seconds count to be recorded. This seconds count rolls over approximately 100 years after the clock begins timing.

Because the elapsed time clock provides the base for system software operations and timer function blocks, *it cannot be reset* from the user program or the programmer. However, the application program can read the current value of the elapsed time clock by using Function Number 16 of the SVC_REQ (SerViCe_REQuest) Function.

Watchdog Timer

A watchdog timer in the MFP is designed to catch catastrophic failure conditions. The timer value for the watchdog timer is 400 milliseconds; this is a fixed value which cannot be changed. The watchdog timer starts from zero at the beginning of each sweep.

If the watchdog timeout value is exceeded, the OK LED goes off, the CPU goes through its power-up sequence and the MFP is left in STOP mode with a watchdog timer fault recorded.

Constant Sweep Timer

The Constant Sweep Timer controls the length of a program sweep when the MFP operates in Constant Sweep Time mode. In this mode of operation, each sweep consumes the same amount of time. For most application programs, the Input Scan, Application Program Logic Scan, and Output Scan do not require exactly the same amount of execution time in each sweep. The value of the Constant Sweep Timer is set by the programmer and can be any value from 5 to 200 milliseconds. The default value is 100 ms.

If the Constant Sweep Timer expires before the completion of the sweep, the previous sweep was not complete, and the `ov_swp` fault is not set, the MFP places an over-sweep alarm in its fault table. At the beginning of the next sweep, the MFP sets the `ov_swp` fault contact. The `ov_swp` contact is reset when the MFP *is not* in Constant Sweep Time Mode or if the time of the last sweep did not exceed the Constant Sweep Timer.

Timer Function Blocks

The MFP supports three types of timer function blocks in the Logicmaster 90 software: on-delay timer, off-delay timer, and elapsed time.

Timed Contacts

Four timed contacts, each of which cycles on and off for a specified interval, are available to the user: .01 second, 0.1 second, 1 second, and 1 minute.

System Security

Overview

Security in the MFP is designed to restrict access to selected functions. The MFP supports two types of system security: password protection and OEM protection. Both types of protection can be accessed through the Status and Control portion of the Logicmaster 90 software or the Hand-Held Programmer.

Password protection and OEM protection are described briefly here. Refer to the *Logicmaster™ 90 Series 90-30/20/Micro Programming Software User's Manual* (GFK-0466) or the *Hand-Held Programmer User's Manual* (GFK-0402) for further details on the use of these system security features.

Password Protection

Privilege Levels

There are four security or *privilege levels* in the MFP password system. The default level (level 4), in a system with no passwords, allows read and write access to all configuration, logic, and data memories. Levels 2–4 can be protected by a password.

There is one password for each of levels 2–4 in the MFP, and each password may be unique. However, the same password can be used for more than one level. Passwords can only be entered or changed using the Logicmaster 90 programmer or the HHP. Passwords are one to four ASCII characters in length. The HHP only allows the ASCII characters 0 to 9 and A to F.

The privileges granted at each level are a combination of that level, plus all lower levels. The levels and their privileges are:

Level 1

Any data, except passwords may be read. This includes all data memories (%I, %Q, %AQ, %R, etc.), fault tables, and all program block types: data, value, and constant. No values may be changed in the MFP. *This is the default level for a system with passwords.*

Level 2

This level allows level 1 privileges plus write access to the data memories (%I, %R, etc.).

Level 3

This level allows levels 1 and 2 privileges plus write access to the application program in STOP mode only.

Level 4

This is the default level in a system with no passwords assigned. This level, the highest, allows levels 1–3 privileges, plus read and write access to all memories, and the ability to display, set, or delete passwords for levels 1–3 in both RUN and STOP mode (configuration data can written only in STOP mode).

Privilege Level Change Requests

To enter or change passwords, the programmer must be in **on-line** mode and communicating with the MFP. Entering or changing passwords requires access to the highest level. If no passwords have been set up for the system, this level is automatically available.

Note

Once passwords have been entered, they can only be changed by:

- Entering the correct password to access the highest-level privileges
- In the configuration software, by placing the master diskette in the system disk drive of the computer and pressing the **ALT** and **O** keys. (It is important to keep the original software master diskettes in a secure location because this allows passwords to be overridden. .)

A programmer requests a privilege level change by supplying the new privilege level and the password for that level. A privilege level change will be denied if the password sent by the programmer does not agree with the password stored in the MFP's password access table for the requested level. If you attempt to access or modify information in the MFP using the HHP without the proper privilege level, the HHP will respond with an error message stating that access is denied.

When communicating over a serial link, a privilege level change remains in effect only as long as communications between the MFP and the programmer are intact. There does not need to be any activity, but the communications link must not be broken. If there is no communication for 15 seconds, the privilege level returns to the highest unprotected level.

When the Logicmaster 90 programmer is connected through the serial connection, either the MFP or the Logicmaster programmer may detect a disconnect. The MFP detects a disconnect of the HHP using a dedicated hardware signal. When the MFP is reconnected to the programmer, Logicmaster 90 requests the protection status of each privilege level from the MFP. Logicmaster 90 then requests the MFP to move to the highest unprotected level, thereby giving the programmer access to the highest unprotected level without it having to request any particular level. When the HHP is reconnected to the MFP, the MFP reverts to the highest unprotected level.

OEM Protection

The OEM protection feature provides a higher level of security than password protection and is used by an original equipment manufacturer to further restrict access to program logic and configuration parameters. When OEM protection is enabled (locked), the user has no access to the logic program, and read-only access to the configuration. The OEM protection state is retentive across a power cycle.

Refer to the *Logicmaster™ 90 Series 90-30/20/Micro Programming Software User's Manual* (GFK-0466), and to the Logicmaster 90 on-line HELP screens for details on the use of this feature.

Diagnostic Data

Diagnostic bits are available in the %S memory that indicate a mismatch in I/O configuration. Refer to Chapter 6 for more information on fault handling.

Flash Memory

The MFP provides flash memory for non-volatile user-program storage and for system firmware. In addition, the **Read/Write/Verify EE/Flash PROM with PLC User Memory** function, initiated from either the Logicmaster 90 software or the HHP, uses flash memory for storage of the configuration and reference data. Because the executable version of the user program is already resident in the non-volatile flash memory, a separate copy of the user program is not maintained for the Read/Write/Verify EE/Flash PROM function. However, separate copies of the User Configuration and Reference Tables are maintained in the EEPROM/FLASH areas of the flash memory.

In addition, it should be noted that editing the user program with the HHP uses RAM memory for the edited copy of the user program. If you do not save the edited version of the program to flash memory, the changes will be lost. See “Storing the User Program Using the HHP” on page 4-4, for the key sequence for this procedure.

Chapter 6

Diagnostics

This chapter provides a guide to troubleshooting the MFP and consists of two sections:

- **Power-Up Diagnostics** describes how to use the LED blink codes that the MFP generates if the unit fails the power-up self-test described in Chapter 2.
- **Faults and Fault Handling** discusses how the MFP handles system faults. These faults can be diagnosed and corrected using Logicmaster 90 software or the Hand-Held Programmer.

Power-up Diagnostics

If the MFP fails the power-up self-test (see page 2-4), it will generate an error message in the form of an LED blink code.

Table 6-1. Power-up Diagnostic LED Blink Error Codes

Number of Blinks		Error
RUN LED	OK LED	
1	1	Flagsor ALU failed
1	2	Bad registers
1	3	Bad stack mechanism
1	4	Bad stack memory area
1	5	DMA 0 transfer failed
1	6	DMA 1 transfer failed
1	7	DMA 2 transfer failed
1	8	DMA 3 transfer failed
1	9	Addr line fail
2	1	Timer 0 not counting
2	2	Timer 1 not counting
2	3	Timer 2 not counting
2	4	Timer 3 not counting
2	5	Timer 4 not counting
2	6	Interrupt vector RAM failed
2	7	Bad diagnostics memory area
2	8	Bad cache memory area
3	1	Bad system heap RAM
3	2	WDT (watchdog timer) timeout
3	3	XILINX test failed
9	9	Other error

Faults and Fault Handling

Faults occur in the MFP when certain failures or conditions that affect the operation and performance of the system occur. These conditions may affect the ability of the MFP to control a machine or process.

Fault Handling

The condition or failure itself is called a *fault*. When a fault has been received and processed by the *Alarm Processor* software in the CPU, it is called an *alarm*. Faults are recorded in a fault table and displayed on either the MFP Fault Table screen or the I/O Fault Table screens in the Logicmaster 90 programming software.

More information on faults and fault handling can be found in the *Logicmaster Series 90-30/20/Micro Programming Software User's Manual* (GFK-0466) and the *Logicmaster Series 90-30/20/Micro 90-30 Programmable Controllers Reference Manual* (GFK-0467). For information on error detection and correction for Statement List programs, refer to the *Series 90-30 and 90-20 Hand-Held Programmer Manual* (GFK-0402).

Classes of Faults

The MFP detects three classes of faults: internal failures, external failures, and operational failures. Following are examples of these failures.

- Internal Failures
 - Non-responding circuit boards
 - Memory checksum errors
- External Failures
 - Sequence fault
- Operational Failures
 - Communication failures
 - Configuration failures
 - Password access failures

System Response to Faults

Some faults can be tolerated, while others require that the system be shut down. I/O failures may be tolerated by the system, but may be intolerable by the application or the process being controlled. Operational failures can normally be tolerated. MFP faults have two attributes:

- Fault Table Affected:** I/O Fault Table
PLC Fault Table
- Fault Action:** Fatal
Diagnostic
Informational

Fatal faults are recorded in the appropriate table, diagnostic variables (if any) are set, and the system is halted. **Diagnostic** faults are recorded in the appropriate table and any diagnostic variables are set. **Informational** faults are only recorded in the appropriate table. Possible fault actions are listed in Table 6-2.

Table 6-2. Fault Actions

Fault Action	Response by CPU
Fatal	Log fault in Fault Table Set fault references GotoSTOP/FAULT mode
Diagnostic	Log fault in Fault Table Set fault references
Informational	Log fault in Fault Table

Fault groups, their fault actions, the fault tables affected, and the mnemonic for system discrete (%S) points that are affected are listed in Table 6-3.


Table 6-3. Fault Summary

Fault Group	Fault Action	Fault Table	Special Discretes			
System Configuration Mismatch	Fatal	PLC Fault Table	sy_ft	any_ft	sy_pres	cfg_mm
PLC CPU Hardware Failure	Fatal	PLC Fault Table	sy_ft	any_ft	sy_pres	hrd_cpu
Program Checksum Failure	Fatal	PLC Fault Table	sy_ft	any_ft	sy_pres	pb_sum
Low Battery	Diagnostic	PLC Fault Table	sy_ft	any_ft	sy_pres	low_bat
PLC Fault Table Full	Diagnostic	-	sy_full			
I/O Fault Table Full	Diagnostic	-	io_full			
Application Fault	Diagnostic	PLC Fault Table	sy_ft	any_ft	sy_pres	apl_ft
No User Program on Power-up	Fatal	PLC Fault table	sy_ft	any_ft	no_prog	
Corrupted User RAM	Fatal	PLC Fault Table	sy_ft	any_ft	sy_pres	bad_ram
Password Access Failure	Diagnostic	PLC Fault Table	sy_ft	any_ft	sy_pres	bad_pwd
PLC Software Failure	Fatal	PLC Fault Table	sy_ft	any_ft	sy_pres	sft_cpu
PLC Store Failure	Fatal	PLC Fault Table	sy_ft	any_ft	sy_pres	stor_er
Constant Sweep Time Exceeded	Diagnostic	PLC Fault Table	sy_ft	any_ft	sy_pres	ov_swp
Unknown PLC Fault	Fatal	PLC Fault Table	sy_ft	any_ft	sy_pres	
Unknown I/O Fault	Fatal	I/O fault Table	io_ft	any_ft	io_pres	

Fault Summary References

Fault summary references are set to indicate *what* fault occurred. The fault reference remains on until the MFP is cleared or until the application program clears the fault.

An example of a fault bit being set and then clearing the bit is shown in the following example. In this example, the coil *light_01* is turned on when an over sweep condition occurs. The light and the *ov_swp* contact remain on until the %I0035 contact is closed.



Fault Reference Definitions

The Alarm Processor maintains the states of the 128 system discrete bits in %S memory. These fault references can be used to indicate where a fault has occurred, and what type of fault it is. Fault references are assigned, with a nickname, to %S, %SA, %SB, and %SC memory. These references are available for use in the application program as required. The mnemonic for these discrete bits and a description of each bit is provided in Table 6-4. Some discrete bits are reserved for future use.

Table 6-4. Fault References

Reference	Nickname	Definition
%S0001	fst_scn	Current sweep is the first sweep.
%S0002	lst_scn	Current sweep is the last sweep.
%S0003	T_10MS	0.01 second timer contact
%S0004	T_100MS	0.1 second timer contact
%S0005	T_SEC	1.0 second timer contact
%S0006	T_MIN	1.0 minute timer contact
%S0007	alw_on	Always On
%S0008	alw_off	Always Off
%S0009	sy_full	Set when the PLC Fault Table fills up. Cleared when an entry is removed from the PLC Fault Table and when the PLC Fault Table is cleared.
%S0010	io_full	Set when the I/O Fault Table fills up. Cleared when an entry is removed from the I/O Fault Table and when the I/O Fault Table is cleared.
%S0013	prg_chk	Set when background program check is active.
%SA0002	ov_swp	Set when the PLC detects that the previous sweep took longer than the time specified by the user. Cleared when the PLC detects that the previous sweep did not take longer than the specified time. It is also cleared during the transition from STOP to RUN mode.
%SA0003	aplflt	Set when an application fault occurs. Cleared when the PLC transitions from STOP mode to RUN mode.
%SA0009	cfg_mm	Set when a configuration mismatch is detected during system power-up. Cleared by powering-up the PLC when no mismatches are present.
%SA0010	hrd_cpu	Set when the diagnostics detect a problem with the CPU hardware. Cleared by replacing the CPU module.
%SB0009	no_prog	Set when an attempt is made to put the PLC in RUN mode when there is no executable application program stored in the CPU. Cleared by storing an application program to the CPU and putting the PLC in RUN mode.
%SB0010	bad_ram	Set when the CPU detects corrupted RAM memory at power-up. Cleared when the CPU detects that RAM memory is valid at power-up.
%SB0011	bad_pwd	Set when a password access violation occurs. Cleared when a password is successfully used to gain a privilege level.
%SB0014	stor_er	Set when an error occurs during a programmer store operation. Cleared when a store operation is completed successfully.
%SC0009	anyflt	Set when any fault occurs. Cleared when both fault tables are cleared.
%SC0010	syflt	Set when any fault occurs that causes an entry to be placed in the PLC Fault Table. Cleared when the PLC Fault table is cleared.
%SC0011	ioflt	Set when any fault occurs that causes an entry to be placed in the I/O Fault Table. Cleared when the I/O Fault table is cleared.
%SC0012	sy_pres	Set as long as there is at least one entry in the PLC Fault Table. Cleared when the PLC Fault Table has no entries.
%SC0013	io_pres	Set as long as there is at least one entry in the I/O Fault Table. Cleared when the I/O Fault Table has no entries.

MFP Fault Conditions

The following faults have effects on system operation that are unique to the MFP.

PLC CPU Software Failure

Whenever a PLC CPU Software Failure is logged, the MFP **immediately** goes into a special Error Sweep mode. No activity is permitted when the MFP is in this mode. The only method of clearing this condition is to reset the MFP (i.e., cycle power).

PLC Sequence Store Failure

A **sequencestore** is the storage of program blocks and other data preceded by the special Start-of-Sequence command and ending with the End-of-Sequence command. If communication with a programming device performing a sequence store is interrupted or any other failure occurs that terminates the download, the PLC Sequence Store Failure fault is logged and the data areas being written to are cleared. As long as this fault is present in the system, the MFP will not transition to RUN mode.

Program Block Checksum Failure

A fatal Program Block Checksum Failure will result if you replace the MFP in a Field Control stick with an MFP that has a different ladder program. This feature prevents unexpected I/O behavior that could result if MFPs are swapped.

A copy of the checksum of the ladder program that is loaded in the MFP is embedded in the configuration file. When the BIU sends the configuration file, the MFP compares the checksum in the file to the checksum of the ladder program currently loaded in the MFP. If the checksums do not agree, a Program Block Checksum Failure fault is logged in the fault table, and the MFP goes to Stop/Faulted mode.

To correct this situation:

1. Perform either of the following steps.
 - A. Store the correct ladder program to the MFP.
 - or
 - B. Clear the the MFP's memory (if you do not know what the correct ladder program is).
2. Clear the faults and transition modes.

The format of the configuration file that the BIU sends to the MFP is provided in Table 6-5. An example configuration file is provided in Appendix C.

If a configuration is stored to the MFP from the network, you may not know what the checksums should be. If this is the case, fill in 0s for bytes 26 through 29 of the configuration file that is to be sent to the MFP. When the MFP sees 0s in these bytes, it will fill in the checksums and request the BIU to read the configuration file so the BIU's copy of the configuration file will then have the correct checksums. In this special case, the MFP will not go to Stop/Faulted mode.

Table 6-5. Configuration File Format

Byte	Definition
0	number of input reference parameters
1	number of output reference parameters
2,3	byte length of discrete input data (reference parameter 0)
4,5	%I table segment selector (reference parameter 0)
6,7	relative offset for reference parameter 0
8,9	byte length of analog input data (reference parameter 1)
10,11	%AI table segment selector (reference parameter 1)
12,13	relative offset for reference parameter 1
14,15	byte length of output command discrete data (reference parameter 2)
16,17	%Q table segment selector (reference parameter 2)
18,19	relative offset for reference parameter 2
20,21	byte length of analog output data (reference parameter 3)
22,23	%AQ table segment selector (reference parameter 3)
24, 25	relative offset for reference parameter 3
26	number of program checksums
27	additive program checksum
28, 29	LRC program checksum

Accessing Additional Fault Information

The Fault Table displays contain basic information regarding the fault. If more detailed information is needed, a hexadecimal dump of the fault can be obtained by positioning the cursor on the fault entry and pressing the **Ctrl/F** keys simultaneously. The hexadecimal information will be displayed on the line directly below the function key display.

Two faults, **Flash Memory Alarm** and **Watchdog Timer Application Fault**, are unique to the family of Series 90 Micro PLCs, which includes the MFP. Refer to the table below for descriptions and corrective actions for these faults. All other faults applicable to the MFP are described in the *Logicmaster™ 90 Series 90-30/20/Micro Programming Software User's Manual* (GFK-0466).

If you find it necessary to contact Field Service concerning a fault, you should be prepared to tell them the information that is provided in the Fault Table *and the hexadecimal information you see when you press the Ctrl/F keys*. Field Service personnel will give you further instructions.

Table 6-6. MFP CPU Software Faults

Name:	Flash Memory Alarm
Error Code:	BAD_FLASH_OP = 32
Description:	The PLC operating system generates this fault when it detects an internal flash device error during a flash write or erase operation.
Correction:	Display the PLC Fault Table on the Programmer. Contact GE Fanuc PLC Field Service, giving them all the information in the fault table.
Name:	Watchdog Timer Application Fault
Error Code:	SFTWR_WD_EXPIRED = 2
Description:	The logic program execution time exceeds the watchdog setting of 400 ms.
Correction:	Modify program so time is not exceeded.

Technical Help

PLCHotline	
Phone numbers	1-800-828-5747(or804-978-5747)
Internet address	PLCHOTLINE@CHO.GE.COM
Fax number	804-978-5099
GE Fanuc Bulletin Board	Files on this bulletin board are provided by GE Fanuc "as-is" and no warranties apply. The phone number is 804-978-5458 (up to 19200 baud, 8 bits, no parity).
Fax Link	804-978-5824

Instructions and Function Blocks

The MFP supports most 90-30 instruction functions and function blocks. Detailed descriptions of the use of these instructions can be found in the *Series 90-30/20/Micro Programmable Controllers Reference Manual (GFK-0467)*, and the *Series 90-30 and 90-20 Hand-Held Programmer User's Manual (GFK-0402)*.

Basic Instructions (Relay Ladder Contacts and Coils)

Type	Description	Basic Instruction	Mnemonic
Contact	normally open contact	--] [--	&NOCON
	normally closed contact	--] / [--	&NCCON
Coil	normally open coil	--()--	&NOCOIL
	negated coil	--(/)--	&NCCOIL
	set coil	--(S)--	&SLAT
	reset coil	--(R)--	&RLAT
	positive transition coil	--(↑)--	&PCOIL
	negative transition coil	--(↓)--	&NCOIL
	retentive coil	--(M)--	&NOMCOIL
	negated retentive coil	--(/M)--	&NCMCOIL
	retentive set coil	--(SM)--	&SMLAT
	retentive reset coil	--(RM)--	&RMLAT
Link	horizontal link	-----	&HO
	vertical link		&VE

Note

The mnemonics listed for the functions in the following tables are shown as they appear on the Hand-Held Programmer's display.

Timers and Counters

The following four function blocks are updated each time they are encountered in the logic: timers by the amount of time consumed by the last sweep, counters by one count.

Description	Mnemonic	HHP Function Number
Stopwatch timer	TMR	10
On-delay timer	ONDTR	13
Up counter	UPCTR	15
Down counter	DNCTR	16

Math Functions

Each math function can be used on Integer (INT) or Double Integer (DINT) data types.

Description	Mnemonic	HHP Function Number
Add	ADD	60
Subtract	SUB	62
Multiply	MUL	64
Divide	DIV	66
Modulo	MOD	68
Square Root	SQRT	70
Double Precision:		
Add	DPADD	61
Subtract	DPSUB	63
Multiply	DPMUL	65
Divide	DPDIV	67
Modulo	DPMOD	69
Square Root	DPSQRT	71

Conversion Functions

Description	Mnemonic	HHP Function Number
Integer To BCD (16-bit integer to 4-digit binary coded decimal)	BCD	80
BCD To Integer (4-digit binary coded decimal to 16-bit integer)	INT	81

Relational Functions

Description	Mnemonic	HHP Function Number
Equal	EQ	52
NotEqual	NE	53
Greater Than	GT	57
Greater Than or Equal	GE	55
Less Than	LT	56
Less Than or Equal	LE	54
Double Precision:		
Equal	DPEQ	72
NotEqual	DPNE	73
Greater Than	DPGT	77
Greater Than or Equal	DPGE	75
Less Than	DPLT	76
Less Than or Equal To	DPLE	74
Range	&RANG	

Bit Operation Functions

Description	Mnemonic	HHP Function Number
LogicalAnd	AND	23
Logical Or	OR	25
Logical exclusive Or	XOR	27
Logicalinvert	NOT	29
Masked compare	MSKOMP	
Shift bit left	SHL	30
Shift bit right	SHR	31
Rotate bit left	ROL	32
Rotate bit right	ROR	33
Set a bit to 1	BITSET	22
Set a bit to 0	BITCLR	24
Test a bit	BITTST	26
Locate a bit set to 1	BITPOS	28

Data Move Functions

Description	Mnemonic	HHP Function Number
Constant block move	BMOVW	43
Block clear	BLKCL	44
Bit sequencer	SEQB	47
Shift register, word	SHFRW	45
Shift register, bit	SHFRB	46
Constant block move, integer	BMOVI	38
Multiple word move	MOVWN	42
Multiple integer move	MOVIN	37
Multiple bit move	MOVBN	40
Communications request	COMRQ	88

Control Functions

Description	Mnemonic	HHP Function Number
Terminate program execution	ENDSW	0
No operation	NOOP	1
Nested jump	JUMP	3
Nested master control relay	MCR	4
Target number for jump	LABEL	7
Master control sequence end	ENDMCR	8
DoI/O update*	DOIO	85
System service request:	SVCREQ	89
#13 Shut down PLC		
#14 Clear fault tables		
#15 Read last fault		
#16 Read elapsed time clock		
PID		
PID - IND algorithm	PIDIND	87
PID - ISA algorithm	PIDISA	86

*The Do I/O function is not supported. Although you can store a DOIO or Fast DOIO function block, it will have no effect in your logic program.

Table Functions

The array search functions supported by the MFP can be operated on by four different data types (Byte, Word, INT, DINT). The array move function can be operated on by five different data types (Bit, Byte, Word, INT, DINT).

Description	Mnemonic	HHP Function Number
Search equal to	SREQ	101 to 104
Search not equal to	SRNE	105 to 108
Search less than	SRLT	109 to 112
Search less than or equal to	SRLE	113 to 116
Search greater than	SRGT	117 to 120
Search greater than or equal to	SRGE	121 to 124
Copy array source to definition	MOVA	130 to 134

User References

Data in Series 90-30/20/Micro PLC programs is referenced by its address in the system. A reference specifies both a memory type and a precise address within that memory type. For example:

```
%I00001    specifies address 1 in input memory
%R00256    specifies address 256 in register memory
```

The % symbol is used to distinguish machine references from nicknames and is only used with Logicmaster 90 software. The % symbol is not used with the Hand-Held Programmer.

The prefix of a user reference indicates where data is stored in the MFP. References in the MFP are either discrete or register data types.

Table 6-7. Range and Size of User References for the MFP

Reference Type	Reference Range	Size
Userprogram logic	Notapplicable	6K words
Discrete inputs, internal	%I0001 - %I0512	512 bits
Discrete outputs, internal	%Q0001 - %Q0512	512 bits
Discreteglobals	%G0001 - %G1280	1280bits
Discreteinternal coils	%M0001 - %M1024	1024bits
Discretetemporary coils	%T0001 - %T0256	256 bits
Systemstatusreferences	%S0001 - %S0032 %SA0001 - %SA0032 %SB0001 - %SB0032 %SC0001 - %SC0032	32 bits 32 bits 32 bits 32 bits
Systemregisterreferences	%R0001 - %R2048	2K words
Analoginputs	%AI0001 - %AI0128	128 words
Analogoutputs	%AQ0001 - %AQ0128	128 words
System registers †	%SR0001 - %SR0016	16 words

† For reference table viewing only; may not be referenced in a user logic program.

References for Fault Reporting

The MFP monitors internal operations for either system or user problems called faults. These faults are reported through the %S references and through an internal fault table. Access to %S information is available through Logicmaster 90 software or with the Hand-Held Programmer. For more details on faults and fault reporting, see Chapter 6.

Reference	Nickname	Description
%SA0002	ov_swp	Exceeded constant sweep time
%SA0009	cfg_mm	Systemconfigurationmismatch
%SB0011	bad_pwd	PasswordAccess Failure

Appendix B

Instruction Timing

The MFP supports many different functions and function blocks. This appendix contains tables showing the memory size in bytes and the execution time in microseconds for each function. Memory size is the number of bytes required by the function in a ladder diagram application program. The execution times shown are as measured *without the BIU sweep enabled*.

Two execution times are shown for each function:

Execution Time	Description
Enabled	Time required to execute the function or function block when power flows into and out of the function. Typically, best-case times are when the data used by the block is contained in user RAM (word-oriented memory) and not in the discrete memory.
Disabled	Time required to execute the function when power flows into the function or function block; however, it is in an inactive state, as when a timer is held in the reset state.

Notes

1. Time (in microseconds) is based on Release 6.0 of Logicmaster 90-30/90-20/Micro software.
2. Timers and counters are updated each time they are encountered in the logic; timers by the amount of time consumed by the last sweep and counters by one count.
3. For bit operation functions, L = the number of bits. For bit position, N = the bit that is set. For data move functions, N = the number of bits or words.
4. For table functions, increment is in units of length specified.
5. Enabled time for single length units of type %R, %AI, and %AQ.
6. JUMPs, LABELs, COMMENTs, and non-nested MCRs are included in the boolean timing spec, which is 1ms/1K logic.
7. Boolean contact execution times are 1.0 μ s for fast %I (%I1–%I64) references and fast %Q (%Q1–%Q64) references. Boolean execution times are 1.2 μ s for normal inputs and 1.6 μ s for normal outputs.

Instruction Timing

Group	Function	Execution Time		Increment	Size (bytes)
		Enabled (μ sec.)	Disabled (μ sec.)		
Coils/Relays	Coils/Relays	See note 7 on page B-1.		-	2
Timers	Off Delay Timer	30.4	38.4	-	15
	On Delay Timer	39.2	31.2	-	15
	Elapsed Timer	35.2	28.0	-	15
Counters	Up Counter	41.6	40.8	-	11
	Down Counter	41.	41.6	-	11
Math	Addition (INT)	29.6	-	-	13
	Addition (DINT)	30.4	-	-	13
	Subtraction (INT)	28.8	-	-	13
	Subtraction (DINT)	30.4	-	-	13
	Multiplication (INT)	32.8	-	-	13
	Multiplication (DINT)	61.6	-	-	13
	Division (INT)	40.0	-	-	13
	Division (DINT)	65.6	-	-	13
	Modulo Division (INT)	40.8	-	-	13
	Modulo Division (DINT)	66.4	-	-	13
	Square Root (INT)	52.0	-	-	-
	Square Root (DINT)	90.4	-	-	-
	Relational	Equal (INT)	19.2	-	-
Equal (DINT)		22.4	-	-	9
Not Equal (INT)		19.2	-	-	9
Not Equal (DINT)		22.4	-	-	9
Greater Than (INT)		19.2	-	-	9
Greater Than (DINT)		22.4	-	-	9
Greater Than/Equal (INT)		19.2	-	-	9
Greater Than/Equal (DINT)		22.4	-	-	9
Less Than (INT)		19.2	-	-	9
Less Than (DINT)		22.4	-	-	9
Less Than/Equal (INT)		19.2	-	-	9
Less Than/Equal (DINT)		22.4	-	-	9
Range (INT)		25.6	-	-	9
Range (DINT)		28.8	-	-	9

Group	Function	Execution Time		Increment	Size (bytes)
		Enabled (μ sec.)	Disabled (μ sec.)		
Bit Operation	LogicalAND	32.0	-	-	13
	LogicalOR	32.0	-	-	13
	LogicalExclusiveOR	32.0	-	-	13
	LogicalInvert, NOT	27.2	-	-	9
	Shift Bit Left	68.0	7.2	13.06W+1.81B	15
	Shift Bit Right	73.6	6.4	13.66W+1.92B	15
	Rotate Bit Left	78.4	-	14.26W+1.87B	15
	Rotate Bit Right	77.6	-	4.15W+2.6B	15
	Bit Position	36.0	-	-	13
	Bit Clear	35.2	-	-	13
	Bit Test	25.6	-	-	13
	Bit Set	35.2	-	-	13
	Mask Compare (WORD)	92.0	-	12.86W+1.65B	25
	Mask Compare (DWORD)	95.2	-	25.38W+1.14B	25
	Data Move	Move (INT)	32.0	-	4.56W
Move (BIT)		42.4	-	4.06W	13
Move (WORD)		32.0	-	4.06W	13
Block Move		53.6	-	-	
Block Clear		27.2	-	3.37W	9
Shift Register (BIT)		83.2	-	0.176B	15
Shift Register (WORD)		42.4	-	6.34W	15
Bit Sequencer		40.8	19.2	-	15

Group	Function	Execution Time		Increment	Size (bytes)
		Enabled (μ sec.)	Disabled (μ sec.)		
Table	Array Move				
	INT	65.6	5.6	7.13W	21
	DINT	72.8	5.6	14.64W	21
	BIT	98.4	4.8	5.14B	21
	BYTE	61.6	5.6	3.52B	21
	Search Equal				
	INT	42.4	4.8	2.90W	19
	DINT	46.4	4.8	5.89W	19
	BYTE	41.6	4.8	2.35B	19
	Search Not Equal				
	INT	42.4	4.8	2.90W	19
	DINT	46.4	4.8	5.89W	19
	BYTE	41.6	4.8	2.35B	19
	Search Greater Than/Equal				
	INT	42.4	4.8	2.90W	19
	DINT	46.4	4.8	5.89W	19
	BYTE	41.6	4.8	2.35B	19
	Search Greater Than				
	INT	42.4	4.8	2.90W	19
	DINT	46.4	4.8	5.89W	19
	BYTE	41.6	4.8	2.35B	19
	Search Less Than				
	INT	42.2	4.8	2.90W	19
	DINT	46.4	4.8	5.89W	19
BYTE	41.6	4.8	2.35B	19	
Search Less Than/Equal					
INT	42.4	4.8	2.90W	19	
DINT	46.4	4.8	5.89W	19	
BYTE	41.6	4.8	2.35B	19	
Conversion	Convert to INT	23.2	-	-	9
	Convert to BCD-4	20.8	-	-	9
Control	DoI/O*	-	-	-	12
	PID-ISA Algorithm	-	60.8	-	15
	PID-IND Algorithm	-	60.8	-	15
	Service Request				
	#14	143.2	-	-	-
	#15	66.4	-	-	9
	#16	66.4	-	-	-
	#18	27.2	-	-	-
NestedMCR/ NestedENDMCR	20.0	8	-	8	

*The Do I/O function is not supported. Although you can store a DOIO or Fast DOIO function, it will have no effect in your logic program.

Appendix C

Configuration File Format

If the BIU does not have a valid configuration for the MFP at powerup, it will obtain a default configuration from the MFP. The configuration file for the MFP (and all other smart modules) starts with the number of input reference parameters and the number of output reference parameters, followed by the reference parameter data. For each reference parameter, the order of data items is: data byte length, data table selector, and finally, data offset. Reference parameters must be in the following order: %I, %AI, %Q, %AQ.

Table C-1. Example Configuration File

Byte	Value	Definition
0	2	number of input reference parameters
1	2	number of output reference parameters
2,3	32	byte length of discrete input data (sequence id 0)
4,5	16	%I table segment selector
6,7	2	relative offset from start of selected table
8,9	16	byte length of analog input data (sequence id 1)
10,11	10	%AI table segment selector
12,13	0	relative offset from start of selected table
14,15	2	byte length of output command discrete data (sequence id 2)
16,17	18	%Q table segment selector
18,19	8	relative offset from start of selected table
20,21	12	byte length of analog output data (sequence id 3)
22,23	16	%AQ table segment selector
24, 25	0	relative offset from start of selected table
26	0	number of program checksums
27	0	additive program checksum
28, 29	0	LRC program checksum

A

Alarm Processor software, 6-3, 6-5

B

Backplane driver interrupts, 5-5

Baud rate settings, 4-2

Bit operation functions, A-3

Bits, transition, 5-7

Bulletin board, 6-9

Bus Interface Unit
 configuring, 3-1
 default/hold last state configuration,
 3-10, 3-22-3-23
 configuring, 3-16

Byte Length, 3-22

C

Cable connections
 Hand-Held Programmer, 2-5
 work station interface, 2-7

Catalog numbers
 BIU, IC670GBI002, 1-1
 Cables
 IC690CBL303, 2-8
 IC690CBL701, 2-8
 IC690CBL702, 2-8
 IC690CBL705, 2-8
 Converter, IC690ACC901, 2-8, 2-9
 HHM, IC660HHM501, 2-1
 HHP, IC693PRG300, 1-3, 1-7, 2-5
 HHP Memory Card, IC693ACC303, 1-7,
 4-3
 PLC, IC750MFP100, 1-7
 Software, IC641SWP301L, 304J, 306F,
 307E, 1-3
 Software, Cable Kit & Manuals,
 IC640HWP300, 1-7, 2-5, 2-7
 WSI board, IC647WMI920, 2-7

Clearing memory, 4-5

Clock, elapsed time, 5-10

Clocks and timers, 5-10

Communications link, broken, 5-12

Compatibility, 1-3

Configuration
 BIU, 1-6
 default for MFP, 3-1
 MFP, 1-6
 using HHP, 4-3
 using Logicmaster 90 software, 4-6
 parameters for MFP, 4-2

Configuration and register data, storing to
 flash, 4-5

Configuration file
 example, C-1
 format, 6-8

Connectors, 1-4

Constant sweep time mode, 5-5

Control functions, A-4

Conversion functions, A-2

CPU, features, 1-4

D

Data move functions, A-4

Data structure, 5-6

Datagrams, 4-7
 Stop/Nd/O, 4-7
 WRITE CONFIGURATION, 3-2, 4-8

Default, configuration for MFP in BIU, 3-1

Default/hold last state
 BIU, 3-10
 configuring with Group moves,
 3-22-3-23
 configuring with reference parameters,
 3-16

Destination reference, 3-21

Destination slot, 3-20

Diagnostic data, 5-13

Dimensions, 1-7

Discrete memory reference definitions,
 5-7

Do I/O function, A-4, B-4

E

E-mail address, 6-9

Elapsed time clock, 5-10

Error detection and correction, power-up
 self-test, 2-4

Examples
configuration file format, C-1
reference parameters, 3-4

F

Fault handling, 6-3-6-9
Fault reporting, 1-7, A-6
Fault summary references, 6-5
Faults
Checksum failure, 6-7
classes of, 6-3
Flash memory alarm, 6-9
hexadecimal dump, 6-9
non-configurable, 6-7
PLC CPU software failure, 6-7
PLC sequence store failure, 6-7
reference definitions, 6-5-6-8
references, table of, 6-6
system response to, 6-4
Watchdog Timer Application fault, 6-9
Flash memory, 1-4, 4-2, 5-13
alarm, 6-9
saving configuration and register data
in, 4-5
saving the user program in, 4-4
Format
configuration file, 6-8-6-9, C-1
WRITE CONFIGURATION datagram,
4-8
Function blocks, A-1
Functional characteristics, 1-7
Functional description, 1-4
Functions, B-2

G

GE Fanuc bulletin board, 6-9
Grounding, 2-2
Group data moves, 3-18-3-24
how to configure, 3-19
selective sweep configuration, 3-24

H

Hand-Held Monitor, 3-1

Hand-Held Programmer
configuration screens, 4-3
useful functions, 4-5
Hexadecimal dump, faults, 6-9
HHP, Memory Card, 4-3
Housekeeping, 5-3

I

I/O mapping, 3-2
I/O scanning, 5-3
Indicators, 1-5
power-up sequence, 2-4
Input scan, 5-3
Installation, 2-2-2-3
grounding procedures, 2-2
programmer grounding, 2-2
RS-422 to RS-232 converter, 2-9
Instruction timing, B-2
Instructions, A-1
basic, A-1
Interrupt, from BIU, 5-5

L

LED blink error codes, 2-4, 6-2
LED indicators, 1-5
Levels, privilege
change requests, 5-12
defined, 5-11
Logic solution, 5-4
Loss of module fault, 5-8

M

Math functions, A-2
Memory, clearing, 4-5
Memory allocation, 1-8
Memory size, A-6
Memory types, accessible to group data
moves, 3-18
Micro Field Processor
configuring internal functions, 4-1-4-2
I/O function, configuring, 3-2

specifications, 1-7
 Micro PLC, functional description, 1-4
 Modes, correlation between BIU and MFP,
 5-5
 Move default screen, 3-22

N

Network mapping, 3-10

O

OEM protection, 5-12
 Output scan, 5-4

P

Passwords, 5-11
 Phone numbers, 6-9
 PLC sweep
 software structure, 5-6
 summary, 5-1
 when in STOP mode, 5-5
 Port, RS-422, 1-4
 Power requirements, DC, 1-7
 Power-down conditions, 5-8
 Power-up self-test, 2-4, 6-2
 Power-up sequence, 5-8
 Privilege levels
 change requests, 5-12
 defined, 5-11
 Program structure, 5-6
 Program sweep
 deviations, 5-5
 summary, 5-1
 sweep time contribution, 5-3
 Programmer window, 5-4
 Programming the MFP, Hand-Held Pro-
 grammer, 4-3
 Protocols, 1-1

R

RAM memory backup, 1-4
 Reference parameters
 error messages, 3-17
 examples, 3-4
 HHM screen sequence, 3-14
 how to configure, 3-13
 mapping, 3-3
 Reference types, 5-6, A-6
 discrete memory, 5-7
 References, user, range and size, A-6
 Relational functions, A-3
 RS-422 serial port, 1-4
 RS-422 to RS-232 converter, installation,
 2-9

S

Scan
 input, 5-3
 output, 5-4
 Security, system, 5-11
 Selective sweep, how to configure for
 group moves, 3-24
 Sequence, power-up, 5-8
 Serial port, 1-4
 Series 90-30 PLC, compatibility with, 4-3
 Slot assignments, MFP functions, 4-3
 Slot designations, 3-13
 Software packages, 2-7
 Source reference, 3-21
 Source slot, 3-20
 Specifications
 functional, 1-7
 memory allocation, 1-8
 physical, 1-7
 Stick, 2-2
 Stop mode, Genius command for, 4-7
 Storing the user program, 4-4
 Super Cap backup for RAM memory, 1-4
 SVC_REQ function, 5-10
 Sweep, PLC, 5-1
 Sweep time contribution, 5-3

Symbol, %, A-6

T

Table functions, A-5

Technical help, 6-9

Timed contacts, 5-10

Timer

- constant sweep, 5-10

- system security, 5-11

- watchdog, 5-10

Timer function blocks, 5-10

Timers and counters, A-2

Timing, instruction, B-1

Transition bits, 5-7

Troubleshooting

- Checksum failure, 6-7

- OK indicator blinking, 6-2

- PLC CPU software failure, 6-7

- PLC sequence store failure, 6-7

- RUN LED blinking, 6-2

U

User references, A-6

W

Watchdog timer, 5-10

- application fault, 6-9

Weight, 1-7

WRITE CONFIGURATION datagram, 3-2

- format for, 4-8